Roland

SAMPLEHEADS

SRX-09

EXPANSION BOARD

SRX Series

SR-JV80 Collection Vol.4

World Collection

OWNER'S MANUAL

Before using this unit, carefully read the sections entitled: "USING THE UNIT SAFELY" and "IMPORTANT NOTES" (p. 2; p. 4). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, Owner's manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.

この機器を正しくお使いいただくために、ご使用前に「安全上のご注意」(P.3) と「使用上のご注意」(P.4) をよくお読みください。また、この機器の優れた機能を十分ご理解いただくためにも、この取扱説明書をよくお読みください。取扱説明書は必要なときにすぐに見ることができるよう、手元に置いてください。

Thank you, and congratulations on your choice of the SRX-09 "SR-JV80 Collection Vol.4 World Collection" Wave Expansion Board.

This expansion board contains all of the waveforms in the SR-JV80-05 World, SR-JV80-14 World Collection "Asia," and SR-JV80-18 World Collection "LATIN," along with specially selected titles from waveforms contained in the 17 Country Collection. This board contains new Patches and Rhythm Sets which combine the waveforms in a manner that highlights the benefits of SRX Effects and Matrix Control.

This board contains all kinds of unique string, wind, and percussion instrument sounds, used in ethnic music from Africa, Asia, the Middle East, South and North America, Australia, and Europe.

- Patches: 414
- Rhythm Sets: 12
- Waveforms: 873

Some of the waveforms used on this board are specially selected from waveforms found on the CD-ROM "Whole Lotta Country," produced by SAMPLEHEADS, creator of many high-quality sound libraries.

* *The parameter settings for Patches and Rhythm Sets are optimized for the Fantom series, XV series, JUNO-G, MX-200, RD series with SRX slots, MC-909, VR-760, G-70, and E-80 models, so there are some minor differences in the sounds each instrument produces.*

The included CD-ROM contains data reproducing the original sounds of the SR-JV80-05, SR-JV80-14, and SR-JV80-18. (Compatible models: Fantom (FA-76), XV-5080, XV-5050, XV-3080, XV-88, XV-2020)

This expansion board utilizes a new format. Check the system program version for your instrument, and if a relevant upgrade is available, upgrade your instrument using the appropriate system update program on the included CD-ROM. (See p. 23.)
This program applies to the SRX-01–09.

このたびは、ウェーブ・エクスパンション・ボード SRX-09「SR-JV80 Collection Vol.4 World Collection」をお買い上げいただき、まことにありがとうございます。

このエクスパンション・ボードは SR-JV80-05 World、14 World Collection "Asia"、18 World Collection "LATIN" に搭載されていたウェーブフォームを完全収録、17 Country Collection に搭載されていたウェーブフォームから一部タイトルを厳選して収録しています。

これらのウェーブフォームを組み合わせた SRX 仕様の Effect、Matrix Control を生かした新規 パッチ、リズム・セットを搭載しています。

アフリカ、アジア、中近東、南米、北米、オーストラリア、ヨーロッパ等、世界中のユニークで様々な弦楽器、管楽器、打楽器などの各種民族楽器の音色を収録しています。

- パッチ 414 種類
- リズム・セット 12 種類
- ウェーブフォーム 873 種類

本製品のウェーブフォームの一部は高品位なサウンドライブラリーを数多く製作している SAMPLEHEADS 社の CD-ROM「Whole Lotta Country」の中からセレクトしたウェーブフォームを使用しています。

※ 各パッチ／リズム・セットは Fantom シリーズ、XV シリーズ、JUNO-G、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760 の各機種ごとに最適なパラメーター設定を行っていますので、それぞれ出音が異なることがあります。

付属の CD-ROM に SR-JV80-05、14、18 のオリジナル音色を再現するデータが収録されています。(対応機種：Fantom (FA-76)、XV-5080、XV-5050、XV-3080、XV-88、XV-2020)

このエクスパンション・ボードは新フォーマットを採用しています。お使いの機種のシステム・プログラム・バージョンをご確認の上、バージョン・アップ対象の場合は、付属 CD-ROM に収録されているシステム・アップデート・プログラムでバージョン・アップしてからご使用ください。(P.23 をご覧ください。)
このアップデートプログラムは SRX-01 ～ 09 で使用出来ます。

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠WARNING and ⚠CAUTION Notices

⚠WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

⚠	The △ symbol alerts the user to important instructions or warnings.The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The ⃠ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The ● symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠WARNING

- Before using this unit, make sure to read the instructions below, and the Owner's Manual.

- Do not open or perform any internal modifications on the unit.

- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page.

- Never use or store the unit in places that are:
  - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
  - Damp (e.g., baths, washrooms, on wet floors); or are
  - Humid; or are
  - Exposed to rain; or are
  - Dusty; or are
  - Subject to high levels of vibration.

- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.

⚠WARNING

- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit.

- Protect the unit from strong impact.
  (Do not drop it!)

- Before installing the SRX-09, you must first always turn off the Fantom series/XV series/JUNO-G/MX-200/RD series with SRX slots/MC-909/VR-760/G-70/E-80 and unplug its power cord.

- DO NOT play a CD-ROM disc on a conventional audio CD player. The resulting sound may be of a level that could cause permanent hearing loss. Damage to speakers or other system components may result.

⚠ CAUTION

- Never climb on top of, nor place heavy objects on the unit.

- Install the circuit board only into the specified unit (Fantom series/XV series/JUNO-G/MX-200/RD series with SRX slots/MC-909/VR-760/G-70/E-80). Remove only the specified screws during the installation.

- Should you remove screws, make sure to put them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally.

*** In the interest of product improvement, the specifications and/or contents of this package are subject to change without prior notice.**

安全上のご注意

火災・感電・傷害を防止するには

⚠警告と⚠注意の意味について

⚠ 警告	取扱いを誤った場合に、使用者が死亡または重傷を負う可能性が想定される内容を表わしています。
⚠ 注意	取扱いを誤った場合に、使用者が傷害を負う危険が想定される場合および物的損害のみの発生が想定される内容を表わしています。 ※物的損害とは、家屋・家財および家畜・ペットにかかわる拡大損害を表わしています。

図記号の例

	△は、注意（危険、警告を含む）を表わしています。 具体的な注意内容は、△の中に描かれています。 左図の場合は、「一般的な注意、警告、危険」を表わしています。
	⃠は、禁止（してはいけないこと）を表わしています。 具体的な禁止内容は、⃠の中に描かれています。 左図の場合は、「分解禁止」を表わしています。
	● は、強制（必ずすること）を表わしています。 具体的な強制内容は、● の中に描かれています。 左図の場合は、「電源プラグをコンセントから抜くこと」を表わしています。

以下の指示を必ず守ってください

⚠ 警告

- この機器を使用する前に、以下の指示と取扱説明書をよく読んでください。
- この機器を分解したり、改造したりしないでください。
- 修理／部品の交換などで、取扱説明書に書かれていないことは、絶対にしないでください。必ずお買い上げ店またはローランド・サービスに相談してください。
- 次のような場所での使用や保存はしないでください。
  - ○ 温度が極端に高い場所（直射日光の当たる場所、暖房機器の近く、発熱する機器の上など）
  - ○ 水気の近く（風呂場、洗面台、濡れた床など）や湿度の高い場所
  - ○ 雨に濡れる場所
  - ○ ホコリの多い場所
  - ○ 振動の多い場所
- この機器に、異物（燃えやすいもの、硬貨、針金など）や液体（水、ジュースなど）を絶対に入れないでください。

⚠ 警告

- お子様のいるご家庭で使用する場合、お子様の取り扱いやいたずらに注意してください。必ず大人のかたが、監視／指導してあげてください。
- この機器を落としたり、この機器に強い衝撃を与えないでください。
- SRX-09 を取り付ける前に、Fantom シリーズ、XV シリーズ、JUNO-G、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760 の電源を切って電源プラグをコンセントから外してください。
- CD-ROM を、一般のオーディオ CD プレーヤーで再生しないで下さい。大音量によって耳を痛めたり、スピーカーを破損する恐れがあります。

⚠ 注意

- この機器の上に乗ったり、機器の上に重いものを置かないでください。
- 指定の機器（Fantom シリーズ、XV シリーズ、JUNO-G、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760）だけに取り付け、取り付け時には指定されたネジだけを外してください。
- ネジを外した場合は、小さなお子様が誤って飲み込んだりすることのないようお子様の手の届かないところへ保管してください。

※ 製品の仕様および内容は、改良のため予告なく変更することがあります。

IMPORTANT NOTES

When you purchase the SRX-09 expansion board from an authorized Roland dealer, the included sounds and samples are licensed, not sold, to you by Roland Corporation, for commercial use in music production, public performance, broadcast, etc.

You may use any of the included phrases and/or samples in a commercial or non-commercial recording without paying any additional license fees. However, you must strictly adhere to the following crediting guidelines on any music recording that utilize material from SRX-09.

Reproduction or duplication of this collection or any of the sound recording contained in the SRX-09, either as they exist on this expansion board or by any means of reformatting, mixing, filtering, re-synthesizing, processing or otherwise editing for use in another product or for re-sale, is strictly prohibited without the express written consent of Roland. All unauthorized giving, trading, lending, renting, re-issue, re-distribution or re-sale of the sounds included in the SRX-09 are expressly prohibited.

In Plain English: Be creative in your application of the SRX-09 sounds, and keep this library for your use only. DO NOT COPY IT.

Roland constantly monitors other Soundware releases to check for copyright infringements, and will prosecute all piracy and copyright violations to the fullest extent of the law.

THIS LIBRARY IS GUARANTEED TO BE 100% COPYRIGHT CLEAN.

In addition to the items listed under "USING THE UNIT SAFELY" on page 2, please read and observe the following:

Handling CD-ROMs

* *Avoid touching or scratching the shiny underside (encoded surface) of the disc. Damaged or dirty CD-ROM discs may not be read properly. Keep your discs clean using a commercially available CD cleaner.*

Handling the Board

To avoid the risk of damage to internal components that can be caused by static electricity, please carefully observe the following whenever you handle the board.

* *Before you touch the board, always first grasp a metal object (such as a water pipe), so you are sure that any static electricity you might have been carrying has been discharged.*
* *When handling the board, grasp it only by its edges. Avoid touching any of the electronic components or connectors.*
* *Save the bag in which the board was originally shipped, and put the board back into it whenever you need to store or transport it.*

French language for Canadian Safety Standard

Veuillez suivre attentivement les instructions suivantes quand vous manipulez la carte afin d'éviter tout risque d'endommagement des pièces internes par l'électricité statique.

* *Toujours toucher un objet métallique relié à la terre (comme un tuyau par exemple) avant de manipuler la carte pour vous décharger de l'électricité statique que vous auriez pu accumuler.*
* *Lorsque vous manipulez la carte, la tenir par les côtés. Évitez de toucher aux composants ou aux connecteurs.*
* *Conservez le sachet d'origine dans lequel était la carte lors de l'envoi et remettez la carte dedans si vous devez la ranger ou la transporter.*

使用上のご注意

お客様が SRX-09 エクスパンション・ボード（以下、「本製品」といいます）をローランドの正規販売店からお買い上げになった時点で、本製品に含まれる音やサンプルは、ローランド株式会社から、お客様に対して、音楽制作、公共の場での演奏、放送などの商用目的のための使用を許諾したものであって、著作権を譲渡したものではありません。

お客様は、いかなる追加料金を支払うこともなく、本製品に含まれるあらゆるフレーズやサンプルを、商用あるいは非商用目的の録音に使用できます。ただし、お客様が本製品を使用して音楽の録音を行う際は、以下のことにご注意ください。

本製品に含まれるいかなる録音物も、そのままの状態であれ、いかなる手段によって再構成、ミキシング、フィルター加工、再合成、加工処理、その他の編集作業をした状態であれ、ローランドの書面による許可なく、他の製品に含めたり再販売するために複製・複写することを禁止します。また、本製品に含まれるいかなる音も、許可なく贈与、取引、貸与、賃貸、再発行、再配布、再販売することを禁止します。

従って、本製品の音色は音楽制作の範囲でお使いいただくようお願いします。そして、本製品のライブラリーはお客様ご自身の個人的使用の目的の範囲でお使いください。本製品の音色データの複製・複写は禁止します。

ローランドは、著作権侵害がないかどうか、常時他のサウンド・ライブラリーの発売を把握しており、著作権侵害に対しては法的手段を行使する場合があります。

なお、本製品のライブラリーは第三者の著作権を一切侵害していないことを保証します。

3 ページに記載されている「安全上のご注意」以外に、次のことに注意してください。

修理について

※ お客様がこの機器を分解、改造された場合、以後の性能について保証できなくなります。また、修理をお断りする場合もあります。

※ 当社では、この製品の補修用性能部品（製品の機能を維持するために必要な部品）を、製造打切後 6 年間保有しています。この部品保有期間を修理可能の期間とさせていただきます。なお、保有期間が経過した後も、故障箇所によっては修理可能の場合がありますので、お買い上げ店、または最寄りのローランド・サービスにご相談ください。

CD-ROM の取り扱い

※ ディスクの裏面（信号面）に触れたり、傷をつけたりしないでください。データの読み出しがうまくいかないことがあります。ディスクの汚れは、市販の CD 専用クリーナーでクリーニングしてください。

基板の取り扱い

この基板は、静電気により部品が破壊される恐れがあります。基板を取り扱うときは、次の点に注意してください。

※ 基板を持つときは、あらかじめ何らかの金属に触れて、体や衣類にたまっている静電気を放電してください。

※ 基板を持つときは、基板の縁を持ち、部品やコネクターの部分に直接手を触れないでください。

※ 基板を保管するとき、または輸送するときなどは、購入時に基板が入っていた袋（導電袋）に入れてください。

INSTALLING THE WAVE EXPANSION BOARD

* *Turn off your instrument.*

1. Remove the cover located on the top (or rear) of your instrument.

* *When turning the unit upside-down, get a bunch of newspapers or magazines, and place them under the four corners or at both ends to prevent damage to the buttons and controls. Also, you should try to orient the unit so no buttons or controls get damaged.*

* *When turning the unit upside-down, handle with care to avoid dropping it, or allowing it to fall or tip over.*

2. Insert the Wave Expansion Board connector into a connector for an SRX Series slot, while simultaneously inserting the board holders into the holes in the Wave Expansion Board.

* *Do not touch any of the printed circuit pathways or connection terminals.*

* *Never use excessive force when installing a circuit board. If it doesn't fit properly on the first attempt, remove the board and try again.*

3. Use the supplied Installation Tool to turn the holders in the LOCK direction, so the board will be fastened in place.

(To remove the Wave Expansion Board, turn the board holders in the UNLOCK direction, and lift up the board.)

* *When circuit board installation is complete, double-check your work.*

4. Using the screws removed in Step 1, refasten the cover in its original position.

5. Check if the Wave Expansion Board is correctly installed.

* *If the "EXP" display cannot be selected (doesn't appear) in the Waveform Selection Screen (refer to the owner's manual of the instrument you use), remove the Wave Expansion Board and install it properly.*

French language for Canadian Safety Standard

* *Éteindre l'instrument.*

1. Retirer le couvercle situé sur le dessus (ou á l'arrière) de l'instrument.

2. Inserer le connecteur de la carte dans un des creneaux pour la serie SRX tout en enfoncant les supports a carte dans les trous de celle-ci.

* *Ne pas toucher aux circuits imprimés ou aux connecteurs.*

* *Ne jamais forcer lors de l'installation de la carte de circuits imprimés. Si la carte s'ajuste mal au premier essai, enlevez la carte et recommencez l'installation.*

3. Utiliser l'outil d'installation fourni pour tourner les clips de retenue vers la position de blocage (LOCK) de façon á ce que la carte soit retenue en place.

(Pour retirer la carte d'expansion Wave, tourner les clips de retenue de la carte vers la position déblocage (UNLOCK) et retirer la carte en la soulevant.)

* *Quand l'installation de la carte de circuits imprimés est terminée, revérifiez si tout est bien installé.*

4. Remettre la plaque a sa place et la fixer a l'aide des vis enlevees a l'etape 1.

5. S'assurer que la carte d'expansion Wave est installée correctement.

* *S'il est impossible de sélectionner l'affichage "EXP" (il n'apparaît pas) á l'écran de sélection Waveform (se reporter au guide du propriétaire de l'instrument utilisé), retirer la carte d'expansion Wave et la réinstaller correctement.*

ウェーブ・エクスパンション・ボードの取り付けかた

※ 使用機器の電源スイッチをオフにしてください。

1. 使用機器の上部、または背面にあるカバーをはずします。

※ 本体を裏返す際は、ボタン、つまみなどを破損しないように、新聞や雑誌などを重ねて本体の四隅や両端に敷いてください。また、その際、ボタン、つまみなどが破損しないような位置に配置してください。

※ 本体を裏返す際は、落下や転倒を引き起こさないよう取扱いにご注意ください。

2. SRX シリーズ用のスロットのコネクターにウェーブ・エクスパンション・ボードのコネクターを差し込み、同時に基板ホルダーをウェーブ・エクスパンション・ボードの穴にはめ込みます。

※ 回路部やコネクター部には手を触れないでください。

※ 基板を無理に押し込まないでください。装着しにくい場合、いったん基板を外してやり直してください。

3. 付属の固定用具で基板ホルダーを LOCK 方向に回し、ウェーブ・エクスパンション・ボードを固定します。

（ウェーブ・エクスパンション・ボードを取り外すには、基板ホルダーを UNLOCK 方向に回してから取り外します。）

※ 取り付けを終えたら、正しく取り付けられていることを再度確認してください。

4. 手順 1 で外したネジで、カバーを元通りに取り付けます。

5. ウェーブ・エクスパンション・ボードの取り付けが正しく行われたかを確認します。

※ ウェーブフォームの選択画面（使用機器の取扱説明書参照）で"EXP"が選べない（表示されない）ときは、もう一度ウェーブ・エクスパンション・ボードをつけ直してください。



Position them as shown before you install the board.
Avant l'installation, orienter les supports à carte tel qu'indiqué sur le schéma.
取り付ける前に図のような向きに合わせます

Patch List (1)

For Fantom series/XV series/JUNO-G/MX-200

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category	
1	World Sounds	1	BEAT&GROOVE	
2	Go2China /C2	2	COMBINATION	#
3	Go2India /C2	2	COMBINATION	#
4	The Great W	6	FLUTE	
5	Yuehchin+	4	PLUCKED	
6	Sweet Nylon	2	AC.GUITAR	
7	Tele R&F	3	EL.GUITAR	
8	Tubby Baby	3	BASS	
9	HeavenGender	5	BELL	
10	Gamelan Ems	4	MALLET	
11	Childwood	4	MALLET	
12	La Musette	1	ACCORDION	
13	Essence	4	WIND	
14	Zampona /	1	FLUTE	
15	GipsyTrumpt/	1	AC.BRASS	
16	We Dream }{	4	SOFT PAD	
17	Fun WithPerc	1	PERCUSSION	
18	GuZheng arp	2	SYNTH FX	
19	Feets	4	SOUND FX	
20	World Radio	5	BEAT&GROOVE	
21	ClanAdvances	3	BEAT&GROOVE	
22	Eastern Tour	4	BEAT&GROOVE	
23	Enough!STOP!	3	BEAT&GROOVE	
24	Banjo Phrs	1	BEAT&GROOVE	
25	Guitar Phrs1	1	BEAT&GROOVE	
26	Guitar Phrs2	1	BEAT&GROOVE	
27	PdlStl Phrs	1	BEAT&GROOVE	
28	Asia UFO	4	BEAT&GROOVE	
29	UBeenSoBaa	8	BEAT&GROOVE	
30	Didgeri /	1	BEAT&GROOVE	
31	WorldGroove	3	BEAT&GROOVE	#
32	LoopPhrase 1	5	BEAT&GROOVE	#
33	LoopPhrase 2	5	BEAT&GROOVE	#
34	TABLA groove	2	BEAT&GROOVE	
35	JasonGoEast	5	COMBINATION	#
36	Flu&AcompSRX	3	COMBINATION	
37	Split Floot	2	COMBINATION	#
38	Hot Salsa	2	COMBINATION	#
39	TempBassSolo	2	COMBINATION	#
40	CherryFlower	4	COMBINATION	
41	SplitThisSRX	1	COMBINATION	
42	Crane Dance	4	COMBINATION	
43	LostInMists	1	COMBINATION	
44	Qu DiEnsembl	3	COMBINATION	
45	NasalBlossom	6	COMBINATION	
46	Meditation 1	4	PLUCKED	
47	Art Of Feng	4	PLUCKED	
48	Orient xPres	4	PLUCKED	
49	Padded Sitar	5	PLUCKED	
50	No Worries	4	PLUCKED	
51	IntarMel SRX	4	PLUCKED	
52	Ode 2 An Oud	5	PLUCKED	
53	Fugi-man	6	PLUCKED	
54	China pluck	2	PLUCKED	
55	Yuehchin SRX	1	PLUCKED	
56	Kayakeum	1	PLUCKED	
57	Asian Pizz	3	PLUCKED	
58	PiPa SRX	3	PLUCKED	
59	Koto SRX	1	PLUCKED	
60	Shamisen SRX	2	PLUCKED	
61	Sanshin SRX	1	PLUCKED	
62	Yang Qin trm	1	PLUCKED	
63	Yang Qin/Mod	3	PLUCKED	
64	SultanPalace	4	PLUCKED	
65	Marco Polo	3	PLUCKED	
66	Bandolim SRX	1	PLUCKED	
67	K.Bandolim	2	PLUCKED	
68	Afro Harp	3	PLUCKED	
69	Ethnhit!	8	PLUCKED	
70	OctaHarp+	2	PLUCKED	
71	St.GuZhngSRX	2	PLUCKED	
72	Zheng Zither	4	PLUCKED	
73	Distance	5	PLUCKED	
74	Mandolin/Mod	4	PLUCKED	
75	Mandolin	2	PLUCKED	
76	Mando Club	3	PLUCKED	
77	MdlnTrmStSRX	4	PLUCKED	
78	Drone Sitar	1	PLUCKED	
79	Conch&Sitar	6	PLUCKED	
80	Punjab Rocks	4	PLUCKED	
81	Pas2IndiaSRX	3	PLUCKED	
82	Rain Drone	3	PLUCKED	
83	SitarGlisSRX	1	PLUCKED	
84	Tambura SRX	2	PLUCKED	
85	TambDroneSRX	1	PLUCKED	
86	St.SanturSRX	2	PLUCKED	
87	SanturTrmSRX	1	PLUCKED	
88	Santur /Mod	2	PLUCKED	
89	Canton	3	PLUCKED	
90	HamrDulcimer	2	PLUCKED	
91	3D Dulcimer	3	PLUCKED	
92	Zither	1	PLUCKED	
93	Magic Pluck	3	PLUCKED	
94	Biwa SRX	2	PLUCKED	
95	Biwa Menu	1	PLUCKED	
96	BerimbauMenu	1	PLUCKED	
97	Berimbau	2	PLUCKED	
98	JawHarp Menu	1	PLUCKED	
99	Steel Rhythm	1	AC.GUITAR	
100	SoloSteelGtr	3	AC.GUITAR	
101	N'Ville Soft	3	AC.GUITAR	
102	Spruce Top	2	AC.GUITAR	
103	Procssd AGtr	4	AC.GUITAR	
104	High Strung	1	AC.GUITAR	
105	Compresd D18	1	AC.GUITAR	
106	12 String	2	AC.GUITAR	
107	Mixed 12Str1	2	AC.GUITAR	
108	Mixed 12Str2	3	AC.GUITAR	
109	Ac Gtr 12stg	2	AC.GUITAR	
110	No Borders	4	AC.GUITAR	
111	Loose 12Str	3	AC.GUITAR	
112	Living R.Gtr	4	AC.GUITAR	
113	Dobro Modro	2	AC.GUITAR	
114	ResonatorGtr	2	AC.GUITAR	
115	Ac.Gtrs SRX	2	AC.GUITAR	
116	2 Players	4	AC.GUITAR	
117	Solo RequGtr	4	AC.GUITAR	
118	Loose Nylon	4	AC.GUITAR	
119	AcousticBros	4	AC.GUITAR	
120	So Sad Nylon	5	AC.GUITAR	
121	Chinese Duo	4	AC.GUITAR	
122	ChugRunTrSRX	3	AC.GUITAR	
123	Chung Ruan	1	AC.GUITAR	
124	ChungRuanSRX	1	AC.GUITAR	
125	Bottom Ruan	2	AC.GUITAR	
126	RuangGtr SRX	3	AC.GUITAR	
127	Oud SRX	1	AC.GUITAR	
128	BlugrsSldSRX	1	AC.GUITAR	
129	Guitaro SRX	2	AC.GUITAR	
130	Natural Tele	2	EL.GUITAR	
131	Psyche Tele	1	EL.GUITAR	
132	Coral	2	EL.GUITAR	
133	Chorus Twang	4	EL.GUITAR	
134	Pick Licker	3	EL.GUITAR	
135	CleanStrtSRX	2	EL.GUITAR	
136	Velo 335 SRX	2	EL.GUITAR	
137	Right Funky	4	EL.GUITAR	
138	Comp Muted	2	EL.GUITAR	
139	E.GtrMt SRX	1	EL.GUITAR	
140	335VelMt SRX	2	EL.GUITAR	
141	Wide Guitar	1	EL.GUITAR	
142	Dob-Compress	2	EL.GUITAR	
143	Nice Twelvey	4	EL.GUITAR	
144	RotaryCrunch	2	EL.GUITAR	
145	FastRotrySRX	3	EL.GUITAR	
146	EGDynaPikSRX	2	EL.GUITAR	
147	BackingEGSRX	2	EL.GUITAR	
148	Room Slide	1	EL.GUITAR	
149	Pedal Steel	1	EL.GUITAR	
150	Phased P.Stl	3	EL.GUITAR	
151	PureSteelSRX	1	EL.GUITAR	
152	MutedAmbient	4	EL.GUITAR	
153	GtrFX Menu	1	EL.GUITAR	
154	LP Gtr SRX	1	DIST.GUITAR	
155	Tele-Funfken	2	DIST.GUITAR	
156	335 &Cabinet	3	DIST.GUITAR	
157	Tele Licker	3	DIST.GUITAR	
158	Short & Long	2	DIST.GUITAR	
159	NewBeginning	4	FRETTED	
160	Bouzouki	2	FRETTED	
161	Bousoukhit!	8	FRETTED	
162	3ChdStrumSRX	1	FRETTED	
163	Strum Poetic	4	FRETTED	
164	Strum Away	4	FRETTED	
165	Banjo-Mando	3	FRETTED	
166	5StringBanjo	1	FRETTED	
167	Banjo SRX 1	2	FRETTED	
168	Banjo SRX 2	1	FRETTED	
169	Banjo SRX 3	1	FRETTED	
170	Fiddle	2	STRINGS	
171	Fiddle 2002	2	STRINGS	
172	FiddleSwitch	1	STRINGS	
173	Fiddle Sect.	4	STRINGS	
174	FiddleStacto	4	STRINGS	
175	AsianOrcPizz	6	STRINGS	
176	AJapaneseInn	3	STRINGS	
177	Deep Blue	4	STRINGS	
178	Ethnic Ens	4	STRINGS	
179	ChinesOrcSRX	4	STRINGS	
180	ErHu / SRX	1	STRINGS	
181	ErHuSolo SRX	1	STRINGS	
182	ErHu Ld SRX	2	STRINGS	
183	FiddleFXmenu	1	STRINGS	
184	ViolnSoloSRX	1	STRINGS	
185	Comp BabyBss	2	BASS	
186	Baby Bass	1	BASS	
187	Comp Fingerd	2	BASS	
188	Jazz Fing.BS	1	BASS	
189	Live Bass	2	BASS	
190	Flango Bass	3	BASS	
191	Bass Oddesy	2	BASS	
192	6Str Bs SRX1	1	BASS	
193	Muted Bass	1	BASS	
194	6Str/Mt SRX	3	BASS	
195	PickBsHd SRX	1	BASS	
196	PickedBs SRX	1	BASS	
197	Tub Bass	2	BASS	
198	GuitarnBsSRX	2	BASS	
199	GtrrnOct SRX	3	BASS	
200	PacificDream	4	BELL	
201	Meditation 2	3	BELL	
202	HybridKemong	3	BELL	
203	Purify	4	BELL	
204	Asia Bells	2	BELL	
205	Rama Cym SRX	2	BELL	
206	Bell Orchest	5	BELL	
207	Sacred Bells	2	BELL	
208	Spokes	3	BELL	
209	Winter Bells	2	BELL	
210	Wind Bells	1	BELL	
211	BelAngk SRX	2	MALLET	
212	Tcheekolyna	2	MALLET	
213	Wood EPiano	3	MALLET	
214	Kalimba	3	MALLET	
215	Kalimbatch	2	MALLET	
216	VelAfro SRX1	2	MALLET	
217	BsKalimbaSRX	3	MALLET	
218	LogDetunrSRX	2	MALLET	
219	Baateri SRX	3	MALLET	
220	Balafon SRX	3	MALLET	
221	Asian Wood	2	MALLET	
222	Mellow tone	2	MALLET	
223	Glas Mlt SRX	2	MALLET	
224	SteelDr SRX1	1	MALLET	
225	SteelDr SRX2	2	MALLET	
226	Gendrous SRX	3	MALLET	
227	BonangGamSRX	1	MALLET	
228	VelAfro SRX2	2	MALLET	
229	TemleMetlSRX	3	MALLET	
230	Kemong / SRX	3	MALLET	
231	Kane / SRX	1	MALLET	
232	JeGong / SRX	3	MALLET	
233	Jegogn / SRX	1	MALLET	
234	Jublag / SRX	1	MALLET	
235	Reyong / SRX	1	MALLET	
236	Pemade / SRX	1	MALLET	
237	Cajun	2	ACCORDION	
238	D.Accordion	4	ACCORDION	
239	SqueezeBoxSRX	2	ACCORDION	
240	Squeeze Box	2	ACCORDION	
241	St.AcdOp SRX	2	ACCORDION	
242	AcdionOp SRX	1	ACCORDION	
243	Acd ffOp SRX	2	ACCORDION	
244	St.AcdCl SRX	2	ACCORDION	
245	Bluesy	1	HARMONICA	
246	HarmonicaSRX	2	HARMONICA	
247	CuntryHrpSRX	2	HARMONICA	
248	Sessn HrpSRX	1	HARMONICA	
249	Esraj&Mizmar	3	WIND	
250	Before Time	1	WIND	
251	Gagaku Ems	4	WIND	
252	Mizmar solo	1	WIND	
253	PiriSolo SRX	2	WIND	
254	Shahnai SRX	1	WIND	
255	HichirikSRX	2	WIND	
256	Bagpipes SRX	2	WIND	
257	Sheng / SRX	1	WIND	
258	Suona / SRX	1	WIND	
259	VillageDance	4	FLUTE	
260	Indian Ens	4	FLUTE	
261	Nature Loves	4	FLUTE	
262	PanPipes SRX	2	FLUTE	
263	Sad Pipe	1	FLUTE	
264	Shell blow	1	FLUTE	
265	Desert Flute	2	FLUTE	
266	Zampona	2	FLUTE	
267	Isolation	2	FLUTE	
268	Ocarina	2	FLUTE	
269	New IndFlute	1	FLUTE	
270	Qu Di Vib	2	FLUTE	

Patch List (2)

For Fantom series/XV series/JUNO-G/MX-200

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category
271	Bang Di Vib	2	FLUTE
272	New Kawala	1	FLUTE
273	BreathyIndia	3	FLUTE
274	New Shaku	2	FLUTE
275	Shakuhachi	2	FLUTE
276	DreamInColor	4	FLUTE
277	TwinHillyLd	2	FLUTE
278	Snake Eyes	3	AC.BRASS
279	Latin Trumpt	1	AC.BRASS
280	MariachiTpts	3	AC.BRASS
281	Trumpets	3	AC.BRASS
282	GrowlWah/Mod	2	AC.BRASS
283	Muted-Grw /	1	AC.BRASS
284	SoloTuba SRX	1	AC.BRASS
285	LatinTubaSRX	1	AC.BRASS
286	World Orch	7	AC.BRASS
287	Stab&Hold	4	AC.BRASS
288	Indian Radio	8	AC.BRASS
289	Wide Brass	3	AC.BRASS
290	Trombones	4	AC.BRASS
291	Brass Snapz	4	AC.BRASS
292	Brass sfzzZZ	6	AC.BRASS
293	2Tp+Tbn SRX	1	AC.BRASS
294	MemphisHORNS	1	AC.BRASS
295	SectStactSRX	1	AC.BRASS
296	LatinBrasses	2	AC.BRASS
297	Hit & Fall	2	AC.BRASS
298	BrsChd13 SRX	3	AC.BRASS
299	BrsChdMi9SRX	3	AC.BRASS
300	BrsChdMj9SRX	3	AC.BRASS
301	Blow Pad	2	BRIGHT PAD
302	Ceremony	4	BRIGHT PAD
303	Glasses	3	BRIGHT PAD
304	Ambiccordian	6	BRIGHT PAD
305	DroneFlanger	3	BRIGHT PAD
306	Rock Gods	5	BRIGHT PAD
307	ScotlandLass	4	BRIGHT PAD
308	Dry Fishes	6	BRIGHT PAD
309	SteroidBrass	4	BRIGHT PAD
310	Soul revived	4	SOFT PAD
311	Rain Pad	3	SOFT PAD
312	Rising Sun	4	SOFT PAD
313	Ethnopad	3	SOFT PAD
314	Ethno Strngs	6	SOFT PAD
315	& 40 Thieves	5	SOFT PAD
316	TromboSynthy	5	OTHER SYNTH
317	GrandExaltd1	3	OTHER SYNTH
318	Sun Dog	4	OTHER SYNTH
319	TechnoSpirit	4	TECHNO SYNTH
320	Play Softly	4	TECHNO SYNTH
321	WorkerBeetle	3	TECHNO SYNTH
322	Glass Cut	3	TECHNO SYNTH
323	GuruTronics	4	PULSATING
324	DubJazz Trip	4	PULSATING
325	Meditation 2	4	PULSATING
326	Political	4	PULSATING
327	G`day Mate	4	PULSATING
328	Mission	4	ORGAN
329	Jegorgan	3	ORGAN
330	Dyno Conga 1	1	PERCUSSION
331	Dyno Conga 2	1	PERCUSSION
332	Congas+Bongo	1	PERCUSSION
333	DynTimbale 1	1	PERCUSSION
334	DynTimbale 2	1	PERCUSSION
335	TimbaleCuica	1	PERCUSSION
336	Dyno Surdo	1	PERCUSSION
337	Rhythm Sect	4	PERCUSSION
338	Rainstick	1	PERCUSSION
339	Clap & Snap	4	PERCUSSION
340	CowbellRandm	1	PERCUSSION
341	Karachi-Man	4	PERCUSSION
342	That Was Zen	4	PERCUSSION
343	StreetParade	4	PERCUSSION
344	BUK	1	PERCUSSION
345	Gongs	2	PERCUSSION
346	Chenchen /	2	PERCUSSION
347	WisdomWithin	4	PERCUSSION
348	Tabla+	4	PERCUSSION
349	DrumsScene	3	PERCUSSION
350	Doholla Fun	1	PERCUSSION
351	AfricanRhtms	2	PERCUSSION
352	Big Logs SRX	2	PERCUSSION
353	WarDrums SRX	4	PERCUSSION
354	Samba Menu	1	PERCUSSION
355	Shaker Menu	1	PERCUSSION
356	Caixa Menu	1	PERCUSSION
357	Cowbell Menu	1	PERCUSSION
358	JapanPrcMenu	1	PERCUSSION
359	Kabuki Menu	1	PERCUSSION
360	KwangwariSRX	2	PERCUSSION
361	Tuzumi / SRX	1	PERCUSSION
362	KoreaPrcMenu	1	PERCUSSION
363	ChinaPrcMenu	1	PERCUSSION
364	China Menu	1	PERCUSSION
365	ChinaGongSRX	3	PERCUSSION
366	Sanba / SRX	3	PERCUSSION
367	St.ShouBoSRX	4	PERCUSSION
368	AsiaCym Menu	1	PERCUSSION
369	Gong Menu	1	PERCUSSION
370	Gamelan Menu	1	PERCUSSION
371	GamlnPrcMenu	1	PERCUSSION
372	BigBazar SRX	1	PERCUSSION
373	Udu Pot Menu	1	PERCUSSION
374	TablaBy Menu	1	PERCUSSION
375	Rek Menu	1	PERCUSSION
376	Dholak Menu1	1	PERCUSSION
377	Dholak Menu2	1	PERCUSSION
378	Dhol Menu	1	PERCUSSION
379	Egypt Tablah	1	PERCUSSION
380	Madal Menu	1	PERCUSSION
381	AfropercMenu	1	PERCUSSION
382	CommSatelite	6	SYNTH FX
383	Amazone	1	SYNTH FX
384	Tasman Sea	3	SYNTH FX
385	Ethnic FX 1	4	SYNTH FX
386	Ethnic FX 2	4	SYNTH FX
387	SpacetualBoy	4	SYNTH FX
388	Crystal	1	SYNTH FX
389	SpaceLuvSick	6	SYNTH FX
390	HitAscension	4	SYNTH FX
391	Nervous Man	1	SYNTH FX
392	Silk Stream	1	SYNTH FX
393	DerangedMind	3	SYNTH FX
394	PolyDrone	4	SYNTH FX
395	TequillaWorm	5	SYNTH FX
396	GlistenToYou	4	SYNTH FX
397	Dream Harp	2	SYNTH FX
398	Waterfall	2	SYNTH FX
399	Gender 3D	4	SYNTH FX
400	Doom Drum	5	SYNTH FX
401	Stalker	3	SYNTH FX
402	PlasticBones	4	SYNTH FX
403	PakistanVibe	4	SYNTH FX
404	ThusSpokeZtr	5	SYNTH FX
405	Kalissando	4	SYNTH FX
406	Rain Forest	2	SOUND FX
407	AfropunchSRX	4	SOUND FX
408	Dance Tape	8	SOUND FX
409	Zaghruta SRX	2	VOX
410	1,2,3,4! SRX	4	VOX
411	Voices SRX	2	VOX
412	Voice Menu 1	1	VOX
413	Voice Menu 2	1	VOX
414	Voice Menu 3	1	VOX

/: Alternate sound obtained with Key Velocity
/Mod: Alternate sound obtained with Modulation (CC:01)

#: Patches using Phrase Loop Waveforms. The numbers included in the Patch name represent the recommended tempo (B.P.M.).

When playing patches on the expansion board, we recommend that you set all the EFFECTS ON/OFF settings on the Fantom series/XV series to "ON." If such settings are set to "OFF," you may not obtain the intended sound.

* *Note that the Release Time has been set to a fairly long value for some of the patches. As a result, if your sound generator has been set so "Patch Remain" is "ON," the release portion of a previously sounding patch may continue to be heard even after switching to a new patch.*
* *Some of the patches use waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.*
* *Refer to the owner's manual for your instrument for specific instructions on how to play Patches on the expansion board.*
* *On the Fantom series/XV series/JUNO-G/MX-200, you can not select only the patches which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70/E-80.*

/： Key Velocity による切替え音色
/Mod： Modulation (CC:01) による切替え音色

#： フレーズ・ループのウェーブフォームを使用したパッチです。
パッチ・ネームに付いている数字は推奨テンポ（B.P.M.）です。

エクスパンション・ボードのパッチを発音させるときは、Fantom シリーズ /XV シリーズの EFFECTS ON/OFF の設定をすべて ON にして使用することをお勧めいたします。OFF に設定した場合、意図した音色にならないことがあります。

※ パッチの中にはリリース・タイムが長く設定してあるパッチもありますので、音源のパッチ・リメインが ON になっていると音色を切り替えても前のパッチのリリースが残る場合があります。
※ パッチの中には SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。
※ エクスパンション・ボードのパッチを発音させるときは、使用機器の取扱説明書にしたがって、実行してください。
※ Fantom シリーズ /XV シリーズ /JUNO-G/MX-200 では、RD シリーズ（SRX 対応）/MC-909/VR-760 専用のパッチを選ぶことはできません。

Patch List (3)

For RD series (with SRX slots)/MC-909/VR-760/G-70/E-80

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category	
1	World Sounds	1	BEAT&GROOVE	
2	Go2China /C2	2	COMBINATION	#
3	Go2India /C2	2	COMBINATION	#
4	The Great W	6	FLUTE	
5	Yuehchin+	4	PLUCKED	
6	Sweet Nylon	2	AC.GUITAR	
7	Tele R&F	3	EL.GUITAR	
8	Tubby Baby	3	BASS	
9	HeavenGender	5	BELL	
10	Gamelan Ems	4	MALLET	
11	Childwood	4	MALLET	
12	La Musette	1	ACCORDION	
13	Essence	4	WIND	
14	Zampona /	1	FLUTE	
15	GipsyTrumpt/	1	AC.BRASS	
16	We Dream }{	4	SOFT PAD	
17	Fun WithPerc	1	PERCUSSION	
18	GuZheng arp	2	SYNTH FX	
19	Feets	4	SOUND FX	
20	World Radio	5	BEAT&GROOVE	
21	ClanAdvances	3	BEAT&GROOVE	
22	Eastern Tour	4	BEAT&GROOVE	
23	Enough!STOP!	2	BEAT&GROOVE	
24	Banjo Phrs	1	BEAT&GROOVE	
25	Guitar Phrs1	1	BEAT&GROOVE	
26	Guitar Phrs2	1	BEAT&GROOVE	
27	PdlStl Phrs	1	BEAT&GROOVE	
28	Asia UFO	4	BEAT&GROOVE	
29	UBeenSoBaa	7	BEAT&GROOVE	
30	Didgeri /	1	BEAT&GROOVE	
31	WorldGroove	3	BEAT&GROOVE	#
32	LoopPhrase 1	5	BEAT&GROOVE	#
33	LoopPhrase 2	5	BEAT&GROOVE	#
34	TABLA groove	2	BEAT&GROOVE	
35	JasonGoEast	6	COMBINATION	#
36	Flu&AcompSRX	4	COMBINATION	
37	Split Floot	2	COMBINATION	#
38	Hot Salsa	2	COMBINATION	#
39	TempBassSolo	2	COMBINATION	#
40	CherryFlower	4	COMBINATION	
41	SplitThisSRX	1	COMBINATION	
42	Crane Dance	5	COMBINATION	
43	LostInMists	2	COMBINATION	
44	Qu DiEnsembl	3	COMBINATION	
45	NasalBlossom	6	COMBINATION	
46	Meditation 1	4	PLUCKED	
47	Art Of Feng	4	PLUCKED	
48	Orient xPres	4	PLUCKED	
49	Padded Sitar	5	PLUCKED	
50	No Worries	4	PLUCKED	
51	IntarMel SRX	4	PLUCKED	
52	Ode 2 An Oud	5	PLUCKED	
53	Fugi-man	6	PLUCKED	
54	China pluck	2	PLUCKED	
55	Yuehchin SRX	1	PLUCKED	
56	Kayakeum	1	PLUCKED	
57	Asian Pizz	3	PLUCKED	
58	PiPa SRX	3	PLUCKED	
59	Koto SRX	1	PLUCKED	
60	Shamisen SRX	2	PLUCKED	
61	Sanshin SRX	1	PLUCKED	
62	Yang Qin trm	1	PLUCKED	
63	Yang Qin/Mod	3	PLUCKED	
64	SultanPalace	4	PLUCKED	
65	Marco Polo	3	PLUCKED	
66	Bandolim SRX	1	PLUCKED	
67	K.Bandolim	2	PLUCKED	
68	Afro Harp	3	PLUCKED	
69	Ethnhit!	8	PLUCKED	
70	OctaHarp+	3	PLUCKED	
71	St.GuZhngSRX	2	PLUCKED	
72	Zheng Zither	4	PLUCKED	
73	Distance	5	PLUCKED	
74	Mandolin/Mod	4	PLUCKED	
75	Mandolin	2	PLUCKED	
76	Mando Club	3	PLUCKED	
77	MdlnTrmStSRX	4	PLUCKED	
78	Drone Sitar	1	PLUCKED	
79	Conch&Sitar	6	PLUCKED	
80	Punjab Rocks	4	PLUCKED	
81	Pas2IndiaSRX	3	PLUCKED	
82	Rain Drone	3	PLUCKED	
83	SitarGlisSRX	1	PLUCKED	
84	Tambura SRX	2	PLUCKED	
85	TambDroneSRX	1	PLUCKED	
86	St.SanturSRX	2	PLUCKED	
87	SanturTrmSRX	1	PLUCKED	
88	Santur /Mod	2	PLUCKED	
89	Canton	3	PLUCKED	
90	HamrDulcimer	2	PLUCKED	
91	3D Dulcimer	3	PLUCKED	
92	Zither	1	PLUCKED	
93	Magic Pluck	3	PLUCKED	
94	Biwa SRX	2	PLUCKED	
95	Biwa Menu	1	PLUCKED	
96	BerimbauMenu	1	PLUCKED	
97	Berimbau	2	PLUCKED	
98	JawHarp Menu	1	PLUCKED	
99	Steel Rhythm	1	AC.GUITAR	
100	SoloSteelGtr	3	AC.GUITAR	
101	N'Ville Soft	3	AC.GUITAR	
102	Spruce Top	2	AC.GUITAR	
103	Procssd AGtr	4	AC.GUITAR	
104	High Strung	1	AC.GUITAR	
105	Compresd D18	1	AC.GUITAR	
106	12 String	2	AC.GUITAR	
107	Mixed 12Str1	2	AC.GUITAR	
108	Mixed 12Str2	3	AC.GUITAR	
109	Ac Gtr 12stg	2	AC.GUITAR	
110	No Borders	4	AC.GUITAR	
111	Loose 12Str	3	AC.GUITAR	
112	Living R.Gtr	4	AC.GUITAR	
113	Dobro Modro	2	AC.GUITAR	
114	ResonatorGtr	2	AC.GUITAR	
115	Ac.Gtrs SRX	2	AC.GUITAR	
116	2 Players	4	AC.GUITAR	
117	Solo RequGtr	4	AC.GUITAR	
118	Loose Nylon	4	AC.GUITAR	
119	AcousticBros	4	AC.GUITAR	
120	So Sad Nylon	5	AC.GUITAR	
121	Chinese Duo	4	AC.GUITAR	
122	ChugRunTrSRX	3	AC.GUITAR	
123	Chung Ruan	1	AC.GUITAR	
124	ChungRuanSRX	1	AC.GUITAR	
125	Bottom Ruan	2	AC.GUITAR	
126	RuangGtr SRX	2	AC.GUITAR	
127	Oud SRX	1	AC.GUITAR	
128	BlugrsSldSRX	1	AC.GUITAR	
129	Guitaro SRX	2	AC.GUITAR	
130	Natural Tele	2	EL.GUITAR	
131	Psyche Tele	1	EL.GUITAR	
132	Coral	2	EL.GUITAR	
133	Chorus Twang	4	EL.GUITAR	
134	Pick Licker	3	EL.GUITAR	
135	CleanStrtSRX	1	EL.GUITAR	
136	Velo 335 SRX	2	EL.GUITAR	
137	Right Funky	4	EL.GUITAR	
138	Comp Muted	2	EL.GUITAR	
139	E.GtrMt SRX	1	EL.GUITAR	
140	335VelMt SRX	2	EL.GUITAR	
141	Wide Guitar	1	EL.GUITAR	
142	Dob-Compress	2	EL.GUITAR	
143	Nice Twelvey	4	EL.GUITAR	
144	RotaryCrunch	2	EL.GUITAR	
145	FastRotrySRX	3	EL.GUITAR	
146	EGDynaPikSRX	2	EL.GUITAR	
147	BackingEGSRX	2	EL.GUITAR	
148	Room Slide	1	EL.GUITAR	
149	Pedal Steel	1	EL.GUITAR	
150	Phased P.Stl	3	EL.GUITAR	
151	PureSteelSRX	1	EL.GUITAR	
152	MutedAmbient	4	EL.GUITAR	
153	GtrFX Menu	1	EL.GUITAR	
154	LP Gtr SRX	1	DIST.GUITAR	
155	Tele-Funfken	2	DIST.GUITAR	
156	335 &Cabinet	3	DIST.GUITAR	
157	Tele Licker	3	DIST.GUITAR	
158	Short & Long	2	DIST.GUITAR	
159	NewBeginning	4	FRETTED	
160	Bouzouki	2	FRETTED	
161	Bousoukhit!	8	FRETTED	
162	3ChdStrumSRX	1	FRETTED	
163	Strum Poetic	4	FRETTED	
164	Strum Away	4	FRETTED	
165	Banjo-Mando	3	FRETTED	
166	5StringBanjo	1	FRETTED	
167	Banjo SRX 1	2	FRETTED	
168	Banjo SRX 2	1	FRETTED	
169	Banjo SRX 3	1	FRETTED	
170	Fiddle	2	STRINGS	
171	Fiddle 2002	2	STRINGS	
172	FiddleSwitch	1	STRINGS	
173	Fiddle Sect.	4	STRINGS	
174	FiddleStacto	4	STRINGS	
175	AsianOrcPizz	6	STRINGS	
176	AJapaneseInn	3	STRINGS	
177	Deep Blue	4	STRINGS	
178	Ethnic Ens	4	STRINGS	
179	ChinesOrcSRX	4	STRINGS	
180	ErHu / SRX	1	STRINGS	
181	ErHuSolo SRX	1	STRINGS	
182	ErHu Ld SRX	2	STRINGS	
183	FiddleFXmenu	1	STRINGS	
184	ViolnSoloSRX	1	STRINGS	
185	Comp BabyBss	2	BASS	
186	Baby Bass	1	BASS	
187	Comp Fingerd	2	BASS	
188	Jazz Fing.BS	1	BASS	
189	Live Bass	2	BASS	
190	Flango Bass	3	BASS	
191	Bass Oddesy	2	BASS	
192	6Str Bs SRX1	1	BASS	
193	Muted Bass	1	BASS	
194	6Str/Mt SRX	3	BASS	
195	PickBsHd SRX	1	BASS	
196	PickedBs SRX	1	BASS	
197	Tub Bass	2	BASS	
198	GuitarnBsSRX	2	BASS	
199	GtrrnOct SRX	3	BASS	
200	PacificDream	4	BELL	
201	Meditation 2	3	BELL	
202	HybridKemong	3	BELL	
203	Purify	4	BELL	
204	Asia Bells	2	BELL	
205	Rama Cym SRX	2	BELL	
206	Bell Orchest	5	BELL	
207	Sacred Bells	2	BELL	
208	Spokes	3	BELL	
209	Winter Bells	2	BELL	
210	Wind Bells	1	BELL	
211	BelAngk SRX	2	MALLET	
212	Tcheekolyna	2	MALLET	
213	Wood EPiano	3	MALLET	
214	Kalimba	3	MALLET	
215	Kalimbatch	2	MALLET	
216	VelAfro SRX1	2	MALLET	
217	BsKalimbaSRX	3	MALLET	
218	LogDetunrSRX	2	MALLET	
219	Baateri SRX	3	MALLET	
220	Balafon SRX	3	MALLET	
221	Asian Wood	2	MALLET	
222	Mellow tone	2	MALLET	
223	Glas Mlt SRX	2	MALLET	
224	SteelDr SRX1	1	MALLET	
225	SteelDr SRX2	2	MALLET	
226	Gendrous SRX	3	MALLET	
227	BonangGamSRX	1	MALLET	
228	VelAfro SRX2	2	MALLET	
229	TemleMetlSRX	3	MALLET	
230	Kemong / SRX	3	MALLET	
231	Kane / SRX	1	MALLET	
232	JeGong / SRX	3	MALLET	
233	Jegogn / SRX	1	MALLET	
234	Jublag / SRX	1	MALLET	
235	Reyong / SRX	1	MALLET	
236	Pemade / SRX	1	MALLET	
237	Cajun	2	ACCORDION	
238	D.Accordion	4	ACCORDION	
239	SqueezeBoxSRX	2	ACCORDION	
240	Squeeze Box	2	ACCORDION	
241	St.AcdOp SRX	2	ACCORDION	
242	AcdionOp SRX	1	ACCORDION	
243	Acd ffOp SRX	2	ACCORDION	
244	St.AcdCl SRX	2	ACCORDION	
245	Bluesy	1	HARMONICA	
246	HarmonicaSRX	2	HARMONICA	
247	CuntryHrpSRX	2	HARMONICA	
248	Sessn HrpSRX	1	HARMONICA	
249	Esraj&Mizmar	3	WIND	
250	Before Time	1	WIND	
251	Gagaku Ems	4	WIND	
252	Mizmar solo	1	WIND	
253	PiriSolo SRX	2	WIND	
254	Shahnai SRX	1	WIND	
255	HichirikSRX	2	WIND	
256	Bagpipes SRX	2	WIND	
257	Sheng / SRX	1	WIND	
258	Suona / SRX	1	WIND	
259	VillageDance	4	FLUTE	
260	Indian Ens	4	FLUTE	
261	Nature Loves	4	FLUTE	
262	PanPipes SRX	2	FLUTE	
263	Sad Pipe	1	FLUTE	
264	Shell blow	1	FLUTE	
265	Desert Flute	2	FLUTE	
266	Zampona	2	FLUTE	
267	Isolation	3	FLUTE	
268	Ocarina	2	FLUTE	
269	New IndFlute	1	FLUTE	
270	Qu Di Vib	2	FLUTE	

Patch List (4)

For RD series (with SRX slots)/MC-909/VR-760/G-70/E-80

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category
271	Bang Di Vib	2	FLUTE
272	New Kawala	1	FLUTE
273	BreathyIndia	3	FLUTE
274	New Shaku	2	FLUTE
275	Shakuhachi	2	FLUTE
276	DreamInColor	4	FLUTE
277	TwinHillyLd	2	FLUTE
278	Snake Eyes	3	AC.BRASS
279	Latin Trumpt	1	AC.BRASS
280	MariachiTpts	3	AC.BRASS
281	Trumpets	3	AC.BRASS
282	GrowlWah/Mod	2	AC.BRASS
283	Muted-Grw /	1	AC.BRASS
284	SoloTuba SRX	1	AC.BRASS
285	LatinTubaSRX	1	AC.BRASS
286	World Orch	7	AC.BRASS
287	Stab&Hold	5	AC.BRASS
288	Indian Radio	8	AC.BRASS
289	Wide Brass	3	AC.BRASS
290	Trombones	4	AC.BRASS
291	Brass Snapz	4	AC.BRASS
292	Brass sfzzZZ	6	AC.BRASS
293	2Tp+Tbn SRX	1	AC.BRASS
294	MemphisHORNS	1	AC.BRASS
295	SectStactSRX	1	AC.BRASS
296	LatinBrasses	2	AC.BRASS
297	Hit & Fall	2	AC.BRASS
298	BrsChd13 SRX	3	AC.BRASS
299	BrsChdMi9SRX	3	AC.BRASS
300	BrsChdMj9SRX	3	AC.BRASS
301	Blow Pad	2	BRIGHT PAD
302	Ceremony	4	BRIGHT PAD
303	Glasses	3	BRIGHT PAD
304	Ambiccordian	6	BRIGHT PAD
305	DroneFlanger	3	BRIGHT PAD
306	Rock Gods	5	BRIGHT PAD
307	ScotlandLass	4	BRIGHT PAD
308	Dry Fishes	6	BRIGHT PAD
309	SteroidBrass	4	BRIGHT PAD
310	Soul revived	4	SOFT PAD
311	Rain Pad	3	SOFT PAD
312	Rising Sun	4	SOFT PAD
313	Ethnopad	3	SOFT PAD
314	Ethno Strngs	6	SOFT PAD
315	& 40 Thieves	5	SOFT PAD
316	TromboSynthy	3	OTHER SYNTH
317	GrandExaltd1	2	OTHER SYNTH
318	Sun Dog	4	OTHER SYNTH
319	TechnoSpirit	4	TECHNO SYNTH
320	Play Softly	4	TECHNO SYNTH
321	WorkerBeetle	3	TECHNO SYNTH
322	Glass Cut	3	TECHNO SYNTH
323	GuruTronics	4	PULSATING
324	DubJazz Trip	4	PULSATING
325	Meditation 2	4	PULSATING
326	Political	4	PULSATING
327	G`day Mate	4	PULSATING
328	Mission	4	ORGAN
329	Jegorgan	3	ORGAN
330	Dyno Conga 1	1	PERCUSSION
331	Dyno Conga 2	1	PERCUSSION
332	Congas+Bongo	1	PERCUSSION
333	DynTimbale 1	1	PERCUSSION
334	DynTimbale 2	1	PERCUSSION
335	TimbaleCuica	1	PERCUSSION
336	Dyno Surdo	1	PERCUSSION
337	Rhythm Sect	4	PERCUSSION
338	Rainstick	1	PERCUSSION
339	Clap & Snap	4	PERCUSSION
340	CowbellRandm	1	PERCUSSION
341	Karachi-Man	4	PERCUSSION
342	That Was Zen	4	PERCUSSION
343	StreetParade	4	PERCUSSION
344	BUK	1	PERCUSSION
345	Gongs	2	PERCUSSION
346	Chenchen /	2	PERCUSSION
347	WisdomWithin	4	PERCUSSION
348	Tabla+	4	PERCUSSION
349	DrumsScene	3	PERCUSSION
350	Doholla Fun	1	PERCUSSION
351	AfricanRhtms	2	PERCUSSION
352	Big Logs SRX	2	PERCUSSION
353	WarDrums SRX	4	PERCUSSION
354	Samba Menu	1	PERCUSSION
355	Shaker Menu	1	PERCUSSION
356	Caixa Menu	1	PERCUSSION
357	Cowbell Menu	1	PERCUSSION
358	JapanPrcMenu	1	PERCUSSION
359	Kabuki Menu	1	PERCUSSION
360	KwangwariSRX	2	PERCUSSION
361	Tuzumi / SRX	1	PERCUSSION
362	KoreaPrcMenu	1	PERCUSSION
363	ChinaPrcMenu	1	PERCUSSION
364	China Menu	1	PERCUSSION
365	ChinaGongSRX	3	PERCUSSION
366	Sanba / SRX	3	PERCUSSION
367	St.ShouBoSRX	4	PERCUSSION
368	AsiaCym Menu	1	PERCUSSION
369	Gong Menu	1	PERCUSSION
370	Gamelan Menu	1	PERCUSSION
371	GamlnPrcMenu	1	PERCUSSION
372	BigBazar SRX	1	PERCUSSION
373	Udu Pot Menu	1	PERCUSSION
374	TablaBy Menu	1	PERCUSSION
375	Rek Menu	1	PERCUSSION
376	Dholak Menu1	1	PERCUSSION
377	Dholak Menu2	1	PERCUSSION
378	Dhol Menu	1	PERCUSSION
379	Egypt Tablah	1	PERCUSSION
380	Madal Menu	1	PERCUSSION
381	AfropercMenu	1	PERCUSSION
382	CommSatelite	6	SYNTH FX
383	Amazone	1	SYNTH FX
384	Tasman Sea	4	SYNTH FX
385	Ethnic FX 1	4	SYNTH FX
386	Ethnic FX 2	4	SYNTH FX
387	SpacetualBoy	3	SYNTH FX
388	Crystal	1	SYNTH FX
389	SpaceLuvSick	6	SYNTH FX
390	HitAscension	3	SYNTH FX
391	Nervous Man	1	SYNTH FX
392	Silk Stream	1	SYNTH FX
393	DerangedMind	3	SYNTH FX
394	PolyDrone	5	SYNTH FX
395	TequillaWorm	4	SYNTH FX
396	GlistenToYou	5	SYNTH FX
397	Dream Harp	2	SYNTH FX
398	Waterfall	2	SYNTH FX
399	Gender 3D	4	SYNTH FX
400	Doom Drum	5	SYNTH FX
401	Stalker	3	SYNTH FX
402	PlasticBones	4	SYNTH FX
403	PakistanVibe	4	SYNTH FX
404	ThusSpokeZtr	6	SYNTH FX
405	Kalissando	4	SYNTH FX
406	Rain Forest	2	SOUND FX
407	AfropunchSRX	4	SOUND FX
408	Dance Tape	8	SOUND FX
409	Zaghruta SRX	2	VOX
410	1,2,3,4! SRX	4	VOX
411	Voices SRX	2	VOX
412	Voice Menu 1	1	VOX
413	Voice Menu 2	1	VOX
414	Voice Menu 3	1	VOX

/: Alternate sound obtained with Key Velocity
/Mod: Alternate sound obtained with Modulation (CC:01)

#: Patches using Phrase Loop Waveforms. The numbers included in the Patch name represent the recommended tempo (B.P.M.).

* *With some tones, tempos may change suddenly or noise may be produced. This occurs when the tempo is being synchronized, for example to multi-effects or chorus delay times. If the noise becomes noticeable, change the delay time value settings to something other than times corresponding to beats.*

* *Some of the patches use waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.*

* *On the RD series (with SRX slots)/MC-909/VR-760/G-70/E-80, you can not select only the patches which are designed to be used with the Fantom series/XV series/JUNO-G/MX-200.*

/： Key Velocity による切替え音色
/Mod： Modulation (CC:01) による切替え音色

#： フレーズ・ループのウェーブフォームを使用したパッチです。
パッチ・ネームに付いている数字は推奨テンポ（B.P.M.）です。

※ 音色によっては、テンポを急激に変化させるとノイズが出る場合があります。これは、マルチエフェクトやコーラスのディレイ・タイムなどがテンポに同期している場合に発生します。ノイズが気になる場合は、ディレイ・タイムなどの設定を音符以外の値に変更してください。

※ パッチの中には SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。

※ SRX 対応の RD シリーズ /MC-909/VR-760 では、Fantom シリーズ /XV シリーズ /JUNO-G/MX-200 専用のパッチを選ぶことはできません。

Rhythm Set List

For All Instruments

(BANK SELECT MSB: 92; LSB: 19)

No.	RhythmName
1	LatinDrmKit
2	AsiaDrm Kit
3	IndiaDrmKit
4	MidEastDrKit
5	World Phrase
6	Gtr Phrase
7	Latin Menu1
8	Latin Menu2
9	Latin Menu3
10	Asia Menu
11	India Menu
12	MidEast Menu

Rhythm Set Key Assign (1)

For Fantom series/XV series/JUNO-G/MX-200

Note No.	1. LatinDrmKit	2. AsiaDrm Kit	3. IndiaDrmKit	4. MidEastDrKit	5. World Phrase	6. Gtr Phrase
28	SectChd m9	Tsuzumi 2 Hi	--	--	--	--
29	SectChd Mj9	Tsuzumi 2 mf	--	--	--	--
30	TimbalesFil4	Tsuzumi 2 p	--	--	--	--
31	TimbalesFil3	Tsuzumi Hi	--	--	--	--
32	TimbalesFil2	Tsuzumi Lo	--	--	--	--
33	TimbalesFil1	Hyoshigi 2	--	--	--	--
34	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	--	--
35	Fat BD	Maple Kick	Fat BD	Maple Kick	--	--
C2 36	Room Kick 2	Warm Kick	Room Kick 2	Warm Kick	180:LatinPt2	120:Bnjo G
37	Cross Stick2	Cross Stick2	Cross Stick2	Cross Stick2	192:LatinPt1	120:Bnjo A
38	Maple Lo Snr	NaturlHardSN	Maple Lo Snr	NaturlHardSN	96:Cng6/8 1	120:Bnjo B
39	Hand Clap 2	Claps Real	Claps Real	Claps Real	96:Cng6/8 2	120:Bnjo Cm
40	MapleSoft SN	NaturlRimSht	MapleSoft SN	NaturlRimSht	144:CgBolero	120:Bnjo Cm+
41	Studio Tom 4	Studio Tom 4	Studio Tom 4	Studio Tom 4	88:CgCumbia	120:Bnjo G-C
42	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	168:CgChacha	120:BnjoG-C+
43	Studio Tom 3	Studio Tom 3	Studio Tom 3	Studio Tom 3	160:CgMambo	95:EGtr1 G
44	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	104:CgMriach	95:EGtr1 C
45	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	138:CgMarinr	95:EGtr1 D
46	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	126:CgWonwn	95:EGtr2 G
47	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	100:TmblPtn3	95:EGtr2 D
C3 48	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	120:TmblPtn4	140:EGtr3 G
49	Crash Cymbal	Crash Cymbal	Crash Cymbal	Crash Cymbal	132:TmblPtn1	140:EGtr3 C
50	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	132:TmblPtn2	140:EGtr3 D
51	Rock RdCym1	Rock RdCym1	Rock RdCym1	Rock RdCym1	80:PndrPtn1	140:EGtr3 G+
52	Crash 1	Crash 1	Crash 1	Crash 1	108:PndrPtn2	140:EGtr3 C+
53	Bongo 1 Hi	Ban Gu 1	Dhol 2	Rek Dom	138:PndrPtn3	140:EGtr3 D+
54	Tambrin Hit	Asian Gong 3	R8 Tamb	R8 Tamb	132:AgogoPtn	120:PdSt1 C
55	Bongo 1 Lo	Ban Gu 2	Dholak 1	Rek Open	132:BotlePtn	120:PdSt1 D
56	Cowbell Op 1	Mokugyo 1	VDrm Cowbell	VDrm Cowbell	104:BomboPtn	120:PdSt1 G
57	BongoHiSlap1	Ban Gu 3	Dholak 8	Rek Tek	126:SurdoPt1	140:PdSt2 D
58	Cowbell 3	Mokugyo 2	VDrm Cowbell	VDrm Cowbell	108:SurdoPt2	140:PdSt2 G
59	Bongo LoSlap	Ban Gu 4	Dholak 9	Rek Trill	138:CaixaPtn	140:PdSt2 D+
C4 60	Conga Hi Mt	Wadaiko	TablaBaya 1	Afro Feet 1	Samba 1	140:PdSt2 G+
61	Conga Lo Mt	Wadaiko Rim	TablaBayaSld	Slit Drum	Samba 2	Gtr Strum 1
62	Conga Slap	Shimedaiko 2	TablaBaya 3	Afro Feet 2	132:TambrmPt	Gtr Strum 2
63	Conga Hi Op	Sime Taiko	TablaBaya 6	Afro Clap	108:RepnqPt1	Nyln GtrNz 1
64	CongaLoOp f	Taiko	TablaBaya 5	Bendir 1	144:RepnqPt2	Nyln GtrNz 2
65	Timbles HiMt	Tang Gu Mt	TablaBaya Na	Bendir 2	96:Salsa	Bouzki Chd 1
66	Timbles LoOp	Tang Gu Op	TablaBayaTin	Dawul	96:Cumbia	Bouzki Chd 2
67	Agogo 2 Hi	Buk	TablaBayaTun	Sagat Close	116:Mariachi	Bouzki Chd 3
68	Agogo 2 Lo	Buk Rim	TablaBaya 8	Sagat Open	Cuica 2	EG C Bend 1
69	Real Cabasa2	Changgo	VDrmCabasaUp	VDrmCabasaUp	Shaker 1	EG C Bend 2
70	Maracas 2	Ohkawa	VDrm Maracas	VDrm Maracas	Shaker 2	EG D Bend 1
71	ApitoHiShort	Ohkawa 2	VDrmCabasDwn	VDrmCabasDwn	104:Shakin'	EG D Bend 2
C5 72	ApitoLoShort	Kwaengwari f	Madal Da	AfroDrum Flm	Shaker 3	EG D Bend 3
73	Guiro Short2	HuYinLuoH Op	Madal Din	AfroDrum Op1	Didgeridoo 1	EG E Bend 1
74	Guiro Long2	HuYinLuoL Op	Madal Ta	AfroDrum Op2	Didgeridoo 3	EG E Bend 2
75	Claves Lo 2	Shou Luo 1	VDrm Claves	AfroDrum Rat	78:Korea Ph	EG E Bend 3
76	Berimbau Up	Shou Luo 2	VDrm Woodblk	VDrm Woodblk	Korean Ens	EG Slide 1
77	Berimbau Dn	BaliCym Opn	VDrm Woodblk	VDrm Woodblk	Er Hu Phrase	EG Slide 2
78	Cuica Hi 1	BaliCym Cls	FingerSnaps4	TalkingDr Dn	GuZhengArpUp	EG Slide 3
79	Cuica Lo 2	Chenchen Cls	Udu Pot1 Acc	TalkingDr Up	GuZhengArpDn	EG Slide 4
80	Caixa Mute	Chenchen Opn	Udu Pot1 Hi	Doholla Dom	118:ChinaPh1	EG Slide 5
81	Caixa Open2	Kopyak Op	Udu Pot1 Lo	Doholla Roll	132:ChinaPh2	EG Slide 6
82	Caixa Rim	Finger Cym	Udu Pot1 Slp	Doholla Sak	78:GamelnP2	EG Slide 7
83	Caixa Roll2	Ramacymbal	Udu Pot2 Lng	Doholla Stop	122:GamelnP1	EG Rake 1
C6 84	Cajon Rol Hi	Gameran 1	Udu Pot2 Mut	Doholla Tak	Chenchen Ptn	EG Rake 2
85	Cajon Rol Lo	Gameran 2	Udu Pot2 Sht	Doira Dun	Udu Pot MENU	EG Mute
86	Surdo Mute2	Gameran 3	Udu Pot MENU	Doira Tik	92:DholakPh	Fdl 5th 1
87	Surdo Open2	Gameran 4	118:TablaByP	Sarna Bell	118:TablaByP	Fdl 5th 2
88	PandeiroL Hi	Gameran 5	TablaBY 3	Sitar Gliss	Tablah 1	Fdl Riff 1
89	PandeiroL Lo	Gameran 6	Tablah 1	ZaghrutaStop	Tablah 2	Fdl Riff 2
90	PandeiroOpen	Gameran 7	Tablah 2	Yoh Tribe	Tablah 3	--
91	PandeiroMute	Gameran 8	Tablah 3	How Tribe	Tablah 4	--
92	PandeiroL Rm	Gameran 9	Tablah 4	92:DholakPh	Tablah Bend	--
93	PandeiroL Sp	Gameran 10	TablaBY 1	120:Dhol Ph	TablaBY 1	--
94	Quijada	Gameran 11	TablaBY 2	African Ens	TablaBY 2	--
95	Rainstick	Gameran 12	Tablah Bend	Morocco Ens	TablaBY 3	--
C7 96	Metronome 2	Metronome 2	Metronome 2	Metronome 2	120:Dhol Ph	--
97	R8 Click	R8 Click	R8 Click	R8 Click	African Ens	--
98	Metronome 1	Metronome 1	Metronome 1	Metronome 1	Morocco Ens	--
99	180:LatinPt2	78:Korea Ph	--	--	--	--
100	160:CgMambo	132:ChinaPh2	--	--	--	--
101	132:TmblPtn1	78:GamelnP2	--	--	--	--
102	132:AgogoPtn	122:GamelnP1	--	--	--	--
103	104:Shakin'	Chenchen Ptn	--	--	--	--

* *On the Fantom series/XV series/JUNO-G/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70/E-80.*

※ Fantom シリーズ /XV シリーズ /JUNO-G/MX-200 では、RD シリーズ（SRX 対応）/MC-909/VR-760 専用のリズム・セットを選ぶことはできません。

Rhythm Set Key Assign (2)

For Fantom series/XV series/JUNO-G/MX-200

Note No.	7. Latin Menu1	8. Latin Menu2	9. Latin Menu3	10. Asia Menu	11. India Menu	12. MidEast Menu
28	--	--	--	--	--	--
29	--	--	--	--	--	--
30	--	--	--	--	--	--
31	--	--	--	--	--	--
32	--	--	--	--	--	--
33	--	--	--	--	--	--
34	--	--	--	--	--	--
35	--	--	--	--	--	--
C2 36	Agogo 2 Hi	Cuica 3	Surdo Hard	Hyoshigi	Bebarongan 1	Boomerang
37	Agogo 2 Lo	Cuica Hi 1	Surdo Mute	Hyoshigi 2	Bebarongan 2	Clapstick
38	Agogo 3 Hi	Cuica Hi 2	Surdo Mute2	Kane	Bebarongan 3	Afro Zither
39	Agogo 3 Lo	Cuica Lo 1	Surdo Open H	Kane Side	Pelegongan 1	Afro Clap
40	ApitoHiShort	Cuica Lo 2	Surdo Open L	Atarigane	Pelegongan 2	Afro Feet 1
41	ApitoLoShort	Ganza Hard	Surdo Open1	Kwaengwari f	Pelegongan 3	Afro Feet 2
42	Berimbau Dn	Ganza Soft	Surdo Open2	Kwaengwari p	Wadon 1	AfroDrum Flm
43	Berimbau Mut	Guiro Long	Surdo Rim	KwaengwariMt	Wadon 2	AfroDrum Op1
44	Berimbau Opn	Guiro Long2	Surdo Rim 2	Mokugyo 1	Wadon 3	AfroDrum Op2
45	Berimbau Up	Guiro Short	Surdo Soft	Mokugyo 2	Wadon 4	AfroDrum Rat
46	Bongo 1 Hi	Guiro Short2	Tamborim Mut	Ohkawa	Wadon 5	Slit Drum
47	Bongo 1 Lo	Hand Clap 2	Tamborim Opn	Ohkawa 2	Wadon 6	TalkingDr Dn
C3 48	Bongo 2 Hi	MamboBell Mt	Tamborim Slp	Shimedaiko 2	Wadon 7	TalkingDr Up
49	Bongo 2 Lo	MamboBell Op	TamborimMute	Sime Taiko	Dhol 1	Yoh Tribe
50	Bongo Hi Hrd	Maracas 2	TamborimOpen	Taiko	Dhol 2	How Tribe
51	Bongo HiOp f	MaracasUpDwn	TamborimRim	Tsuzumi 2 Hi	Dhol 3	Bendir 1
52	Bongo Lo Hrd	MtlGuiroLng	TamborimRoll	Tsuzumi 2 mf	Dhol 4	Bendir 2
53	Bongo Lo Sft	MtlGuiroSht	Tambrin Hit	Tsuzumi 2 p	Dhol 5	Dawul
54	Bongo LoOp f	PandeiroCrsh	TambrinShake	Tsuzumi Hi	Dholak 1	Doholla Dom
55	Bongo LoOpmf	PandeiroHit	Timbale Hi	Tsuzumi Lo	Dholak 2	Doholla Roll
56	Bongo LoSlap	PandeiroL Hi	Timbale Lo	Wadaiko	Dholak 3	Doholla Sak
57	BongoBell Mt	PandeiroL Lo	Timbale Side	Wadaiko Rim	Dholak 4	Doholla Stop
58	BongoBell Op	PandeiroL Rm	Timbales Rim	Ho	Dholak 5	Doholla Tak
59	BongoHiSlap1	PandeiroL Sp	TimbalesFil1	Yoh	Dholak 6	Doira Dun
C4 60	BongoHiSlap2	PandeiroMute	TimbalesFil2	iYooh	Dholak 7	Doira Tik
61	Cabasa Roll	PandeiroOpen	TimbalesFil3	Yyoo Dude	Dholak 8	Rek Dom
62	Caixa Mute	PandeiroRim	TimbalesFil4	Buk	Dholak 9	Rek Open
63	Caixa Mute2	PandeiroRoll	TimbalesHand	Buk Rim	Dholak Ga	Rek Tek
64	Caixa Open1	PandeiroS Op	Timbles HiMt	Changgo	Dholak Na	Rek Trill
65	Caixa Open2	PandeiroS Rm	Timbles HiOp	Asian Gong 1	Dholak Ta	Sagat Close
66	Caixa Open3	PandeiroS Sp	Timbles LoMt	Asian Gong 2	Dholak Tun	Sagat Open
67	Caixa Rim	Quide Long	Timbles LoOp	Gamelan Gong	Madal Da	Sarna Bell
68	Caixa Roll	Quide Short	TmbSideStick	Asian Gong 3	Madal Din	Sitar Gliss
69	Caixa Roll2	Quijada	SectChd 13th	Asian Gong 4	Madal Ta	Tablah Dom
70	Cajon Hi	Rainstick	SectChd m9	Asian Gong 6	TablaBaya 1	Tablah Rim
71	Cajon Lo	Real Cabasa1	SectChd Mj9	Asian Gong 7	TablaBaya 2	Tablah Roll
C5 72	Cajon Rol Hi	Real Cabasa2	Sabor!	Ban Gu 1	TablaBaya 3	Tablah Tak
73	Cajon Rol Lo	RecoRecoLng	Arriba!	Ban Gu 2	TablaBaya 4	ZaghrutaLoop
74	Caxixi	RecoRecoSht	Ole!	Ban Gu 3	TablaBaya 5	ZaghrutaStop
75	Chekere 1	Repinique1	Uno!	Ban Gu 4	TablaBaya 6	Bull Scream
76	Chekere 2	Repinique2	Dos!	Gu Hi	TablaBaya 7	--
77	Chekere 3	RepiniqueHrd	Tres!	Gu Roll	TablaBaya 8	--
78	Clave!	RepiniqueSft	Quatro!	HuYinLuoH Mt	TablaBaya Ge	--
79	Claves Lo 2	Repique Open	Grito-Hahaha	HuYinLuoH Op	TablaBaya Ka	--
80	Conga Hi Mt	Repique Rim	Grito-Ahaha!	HuYinLuoL Mt	TablaBaya Na	--
81	Conga Hi Op	Repique Roll	Grito-Haahai	HuYinLuoL Op	TablaBaya Te	--
82	Conga Link	SambaBateria	Grito-Rrrrr!	Nao Bo	TablaBaya Ti	--
83	Conga Lo Mt	SambaWhistle	Tiquitito!	Xiao Bo	TablaBayaGin	--
C6 84	Conga Roll	Shaker 1	Grito-Oa Oa!	Asian Gong 5	TablaBayaSld	--
85	Conga Slap	Shaker 2	Grito-Eh Eh!	Shou Luo 1	TablaBayaTin	--
86	Conga Thumb	Shaker Long	Ama ya ahi!	Shou Luo 2	TablaBayaTun	--
87	CongaLoOp f	Shaker Short	Fuego!	Shu Ban 1	Udu Pot1 Acc	--
88	CongaLoOp mf	--	Hey Brazil	Shu Ban 2	Udu Pot1 Hi	--
89	Cowbell 1	--	--	Shu Gu	Udu Pot1 Lo	--
90	Cowbell 2	--	--	Shu Gu Rim	Udu Pot1 Slp	--
91	Cowbell 3	--	--	Tang Gu Mt	Udu Pot2 Lng	--
92	Cowbell Mt 1	--	--	Tang Gu Op	Udu Pot2 Mut	--
93	Cowbell Mt 2	--	--	BaliCym Cls	Udu Pot2 Sht	--
94	Cowbell Op 1	--	--	BaliCym Opn	--	--
95	Cowbell Op 2	--	--	Ceng Ceng	--	--
C7 96	--	--	--	Chenchen Cls	--	--
97	--	--	--	Chenchen Opn	--	--
98	--	--	--	Kopyak Mt	--	--
99	--	--	--	Kopyak Op	--	--
100	--	--	--	Finger Cym	--	--
101	--	--	--	Ramacymbal	--	--
102	--	--	--	Jaw Harp Opn	--	--
103	--	--	--	Jaw Harp Wow	--	--

* *On the Fantom series/XV series/JUNO-G/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70/E-80.*

※ Fantom シリーズ /XV シリーズ /JUNO-G/MX-200 では、RD シリーズ（SRX 対応）/MC-909/VR-760 専用のリズム・セットを選ぶことはできません。

Rhythm Set Key Assign (3)

For RD series (with SRX slots)/MC-909/VR-760/G-70/E-80

Note No.	1. LatinDrmKit	2. AsiaDrm Kit	3. IndiaDrmKit	4. MidEastDrKit	5. World Phrase	6. Gtr Phrase
28	SectChd m9	Tsuzumi 2 Hi	--	--	--	--
29	SectChd Mj9	Tsuzumi 2 mf	--	--	--	--
30	TimbalesFil4	Tsuzumi 2 p	--	--	--	--
31	TimbalesFil3	Tsuzumi Hi	--	--	--	--
32	TimbalesFil2	Tsuzumi Lo	--	--	--	--
33	TimbalesFil1	Hyoshigi 2	--	--	--	--
34	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	--	--
35	Fat BD	Maple Kick	Fat BD	Maple Kick	--	--
C2 36	Room Kick 2	Warm Kick	Room Kick 2	Warm Kick	180:LatinPt2	120:Bnjo G
37	Cross Stick2	Cross Stick2	Cross Stick2	Cross Stick2	192:LatinPt1	120:Bnjo A
38	Maple Lo Snr	NaturlHardSN	Maple Lo Snr	NaturlHardSN	96:Cng6/8 1	120:Bnjo B
39	Hand Clap 2	Claps Real	Claps Real	Claps Real	96:Cng6/8 2	120:Bnjo Cm
40	MapleSoft SN	NaturlRimSht	MapleSoft SN	NaturlRimSht	144:CgBolero	120:Bnjo Cm+
41	Studio Tom 4	Studio Tom 4	Studio Tom 4	Studio Tom 4	88:CgCumbia	120:Bnjo G-C
42	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	168:CgChacha	120:BnjoG-C+
43	Studio Tom 3	Studio Tom 3	Studio Tom 3	Studio Tom 3	160:CgMambo	95:EGtr1 G
44	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	104:CgMriach	95:EGtr1 C
45	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	138:CgMarinr	95:EGtr1 D
46	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	126:CgWonwn	95:EGtr2 G
47	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	100:TmblPtn3	95:EGtr2 D
C3 48	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	120:TmblPtn4	140:EGtr3 G
49	--	--	--	--	132:TmblPtn1	140:EGtr3 C
50	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	132:TmblPtn2	140:EGtr3 D
51	--	--	--	--	80:PndrPtn1	140:EGtr3 G+
52	--	--	--	--	108:PndrPtn2	140:EGtr3 C+
53	Bongo 1 Hi	Ban Gu 1	Dhol 2	Rek Dom	138:PndrPtn3	140:EGtr3 D+
54	Tambrin Hit	Asian Gong 3	R8 Tamb	R8 Tamb	132:AgogoPtn	120:PdSt1 C
55	Bongo 1 Lo	Ban Gu 2	Dholak 1	Rek Open	132:BotlePtn	120:PdSt1 D
56	Cowbell Op 1	Mokugyo 1	VDrm Cowbell	VDrm Cowbell	104:BomboPtn	120:PdSt1 G
57	BongoHiSlap1	Ban Gu 3	Dholak 8	Rek Tek	126:SurdoPt1	140:PdSt2 D
58	Cowbell 3	Mokugyo 2	VDrm Cowbell	VDrm Cowbell	108:SurdoPt2	140:PdSt2 G
59	Bongo LoSlap	Ban Gu 4	Dholak 9	Rek Trill	138:CaixaPtn	140:PdSt2 D+
C4 60	Conga Hi Mt	Wadaiko	TablaBaya 1	Afro Feet 1	Samba 1	140:PdSt2 G+
61	Conga Lo Mt	Wadaiko Rim	TablaBayaSld	Slit Drum	Samba 2	Gtr Strum 1
62	Conga Slap	Shimedaiko 2	TablaBaya 3	Afro Feet 2	132:TambrmPt	Gtr Strum 2
63	Conga Hi Op	Sime Taiko	TablaBaya 6	Afro Clap	108:RepnqPt1	Nyln GtrNz 1
64	CongaLoOp f	Taiko	TablaBaya 5	Bendir 1	144:RepnqPt2	Nyln GtrNz 2
65	Timbles HiMt	Tang Gu Mt	TablaBaya Na	Bendir 2	96:Salsa	Bouzki Chd 1
66	Timbles LoOp	Tang Gu Op	TablaBayaTin	Dawul	96:Cumbia	Bouzki Chd 2
67	Agogo 2 Hi	Buk	TablaBayaTun	Sagat Close	116:Mariachi	Bouzki Chd 3
68	Agogo 2 Lo	Buk Rim	TablaBaya 8	Sagat Open	Cuica 2	EG C Bend 1
69	Real Cabasa2	Changgo	VDrmCabasaUp	VDrmCabasaUp	Shaker 1	EG C Bend 2
70	Maracas 2	Ohkawa	VDrm Maracas	VDrm Maracas	Shaker 2	EG D Bend 1
71	ApitoHiShort	Ohkawa 2	VDrmCabasDwn	VDrmCabasDwn	104:Shakin'	EG D Bend 2
C5 72	ApitoLoShort	Kwaengwari f	Madal Da	AfroDrum Flm	Shaker 3	EG D Bend 3
73	Guiro Short2	HuYinLuoH Op	Madal Din	AfroDrum Op1	Didgeridoo 1	EG E Bend 1
74	Guiro Long2	HuYinLuoL Op	Madal Ta	AfroDrum Op2	Didgeridoo 3	EG E Bend 2
75	Claves Lo 2	Shou Luo 1	VDrm Claves	AfroDrum Rat	78:Korea Ph	EG E Bend 3
76	Berimbau Up	Shou Luo 2	VDrm Woodblk	VDrm Woodblk	Korean Ens	EG Slide 1
77	Berimbau Dn	BaliCym Opn	VDrm Woodblk	VDrm Woodblk	Er Hu Phrase	EG Slide 2
78	Cuica Hi 1	BaliCym Cls	FingerSnaps4	TalkingDr Dn	GuZhengArpUp	EG Slide 3
79	Cuica Lo 2	Chenchen Cls	Udu Pot1 Acc	TalkingDr Up	GuZhengArpDn	EG Slide 4
80	Caixa Mute	Chenchen Opn	Udu Pot1 Hi	Doholla Dom	118:ChinaPh1	EG Slide 5
81	Caixa Open2	Kopyak Op	Udu Pot1 Lo	Doholla Roll	132:ChinaPh2	EG Slide 6
82	Caixa Rim	Finger Cym	Udu Pot1 Slp	Doholla Sak	78:GamelnP2	EG Slide 7
83	Caixa Roll2	Ramacymbal	Udu Pot2 Lng	Doholla Stop	122:GamelnP1	EG Rake 1
C6 84	Cajon Rol Hi	Gameran 1	Udu Pot2 Mut	Doholla Tak	Chenchen Ptn	EG Rake 2
85	Cajon Rol Lo	Gameran 2	Udu Pot2 Sht	Doira Dun	Udu Pot MENU	EG Mute
86	Surdo Mute2	Gameran 3	Udu Pot MENU	Doira Tik	92:DholakPh	Fdl 5th 1
87	Surdo Open2	Gameran 4	118:TablaByP	Sarna Bell	118:TablaByP	Fdl 5th 2
88	PandeiroL Hi	Gameran 5	TablaBY 3	Sitar Gliss	Tablah 1	Fdl Riff 1
89	PandeiroL Lo	Gameran 6	Tablah 1	ZaghrutaStop	Tablah 2	Fdl Riff 2
90	PandeiroOpen	Gameran 7	Tablah 2	Yoh Tribe	Tablah 3	--
91	PandeiroMute	Gameran 8	Tablah 3	How Tribe	Tablah 4	--
92	PandeiroL Rm	Gameran 9	Tablah 4	92:DholakPh	Tablah Bend	--
93	PandeiroL Sp	Gameran 10	TablaBY 1	120:Dhol Ph	TablaBY 1	--
94	Quijada	Gameran 11	TablaBY 2	African Ens	TablaBY 2	--
95	Rainstick	Gameran 12	Tablah Bend	Morocco Ens	TablaBY 3	--
C7 96	--	--	--	--	120:Dhol Ph	--
97	--	--	--	--	African Ens	--
98	--	--	--	--	Morocco Ens	--
99	180:LatinPt2	78:Korea Ph	--	--	--	--
100	160:CgMambo	132:ChinaPh2	--	--	--	--
101	132:TmblPtn1	78:GamelnP2	--	--	--	--
102	132:AgogoPtn	122:GamelnP1	--	--	--	--
103	104:Shakin'	Chenchen Ptn	--	--	--	--

* *On the RD series (with SRX slots)/MC-909/VR-760/G-70/E-80, you can not select only the rhythm sets which are designed to be used with the Fantom series/ XV series/JUNO-G/MX-200.*

* *On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).*

※ SRX 対応のRD シリーズ /MC-909/VR-760 では、Fantom シリーズ / XV シリーズ /JUNO-G/MX-200 専用のリズム・セットを選ぶことはできません。

※ MC-909 では、Note No. 35（B1）から 50（D3）までの 16 鍵分のリズム・トーンのみ使用できます。

Rhythm Set Key Assign (4)

For RD series (with SRX slots)/MC-909/VR-760/G-70/E-80

Note No.	7. Latin Menu1	8. Latin Menu2	9. Latin Menu3	10. Asia Menu	11. India Menu	12. MidEast Menu
28	--	--	--	--	--	--
29	--	--	--	--	--	--
30	--	--	--	--	--	--
31	--	--	--	--	--	--
32	--	--	--	--	--	--
33	--	--	--	--	--	--
34	--	--	--	--	--	--
35	--	--	--	--	--	--
C2 36	Agogo 2 Hi	Cuica 3	Surdo Hard	Hyoshigi	Bebarongan 1	Boomerang
37	Agogo 2 Lo	Cuica Hi 1	Surdo Mute	Hyoshigi 2	Bebarongan 2	Clapstick
38	Agogo 3 Hi	Cuica Hi 2	Surdo Mute2	Kane	Bebarongan 3	Afro Zither
39	Agogo 3 Lo	Cuica Lo 1	Surdo Open H	Kane Side	Pelegongan 1	Afro Clap
40	ApitoHiShort	Cuica Lo 2	Surdo Open L	Atarigane	Pelegongan 2	Afro Feet 1
41	ApitoLoShort	Ganza Hard	Surdo Open1	Kwaengwari f	Pelegongan 3	Afro Feet 2
42	Berimbau Dn	Ganza Soft	Surdo Open2	Kwaengwari p	Wadon 1	AfroDrum Flm
43	Berimbau Mut	Guiro Long	Surdo Rim	KwaengwariMt	Wadon 2	AfroDrum Op1
44	Berimbau Opn	Guiro Long2	Surdo Rim 2	Mokugyo 1	Wadon 3	AfroDrum Op2
45	Berimbau Up	Guiro Short	Surdo Soft	Mokugyo 2	Wadon 4	AfroDrum Rat
46	Bongo 1 Hi	Guiro Short2	Tamborim Mut	Ohkawa	Wadon 5	Slit Drum
47	Bongo 1 Lo	Hand Clap 2	Tamborim Opn	Ohkawa 2	Wadon 6	TalkingDr Dn
C3 48	Bongo 2 Hi	MamboBell Mt	Tamborim Slp	Shimedaiko 2	Wadon 7	TalkingDr Up
49	Bongo 2 Lo	MamboBell Op	TamborimMute	Sime Taiko	Dhol 1	Yoh Tribe
50	Bongo Hi Hrd	Maracas 2	TamborimOpen	Taiko	Dhol 2	How Tribe
51	Bongo HiOp f	MaracasUpDwn	TamborimRim	Tsuzumi 2 Hi	Dhol 3	Bendir 1
52	Bongo Lo Hrd	MtlGuiroLng	TamborimRoll	Tsuzumi 2 mf	Dhol 4	Bendir 2
53	Bongo Lo Sft	MtlGuiroSht	Tambrin Hit	Tsuzumi 2 p	Dhol 5	Dawul
54	Bongo LoOp f	PandeiroCrsh	TambrinShake	Tsuzumi Hi	Dholak 1	Doholla Dom
55	Bongo LoOpmf	PandeiroHit	Timbale Hi	Tsuzumi Lo	Dholak 2	Doholla Roll
56	Bongo LoSlap	PandeiroL Hi	Timbale Lo	Wadaiko	Dholak 3	Doholla Sak
57	BongoBell Mt	PandeiroL Lo	Timbale Side	Wadaiko Rim	Dholak 4	Doholla Stop
58	BongoBell Op	PandeiroL Rm	Timbales Rim	Ho	Dholak 5	Doholla Tak
59	BongoHiSlap1	PandeiroL Sp	TimbalesFil1	Yoh	Dholak 6	Doira Dun
C4 60	BongoHiSlap2	PandeiroMute	TimbalesFil2	iYooh	Dholak 7	Doira Tik
61	Cabasa Roll	PandeiroOpen	TimbalesFil3	Yyoo Dude	Dholak 8	Rek Dom
62	Caixa Mute	PandeiroRim	TimbalesFil4	Buk	Dholak 9	Rek Open
63	Caixa Mute2	PandeiroRoll	TimbalesHand	Buk Rim	Dholak Ga	Rek Tek
64	Caixa Open1	PandeiroS Op	Timbles HiMt	Changgo	Dholak Na	Rek Trill
65	Caixa Open2	PandeiroS Rm	Timbles HiOp	Asian Gong 1	Dholak Ta	Sagat Close
66	Caixa Open3	PandeiroS Sp	Timbles LoMt	Asian Gong 2	Dholak Tun	Sagat Open
67	Caixa Rim	Quide Long	Timbles LoOp	Gamelan Gong	Madal Da	Sarna Bell
68	Caixa Roll	Quide Short	TmbSideStick	Asian Gong 3	Madal Din	Sitar Gliss
69	Caixa Roll2	Quijada	SectChd 13th	Asian Gong 4	Madal Ta	Tablah Dom
70	Cajon Hi	Rainstick	SectChd m9	Asian Gong 6	TablaBaya 1	Tablah Rim
71	Cajon Lo	Real Cabasa1	SectChd Mj9	Asian Gong 7	TablaBaya 2	Tablah Roll
C5 72	Cajon Rol Hi	Real Cabasa2	Sabor!	Ban Gu 1	TablaBaya 3	Tablah Tak
73	Cajon Rol Lo	RecoRecoLng	Arriba!	Ban Gu 2	TablaBaya 4	ZaghrutaLoop
74	Caxixi	RecoRecoSht	Ole!	Ban Gu 3	TablaBaya 5	ZaghrutaStop
75	Chekere 1	Repinique1	Uno!	Ban Gu 4	TablaBaya 6	Bull Scream
76	Chekere 2	Repinique2	Dos!	Gu Hi	TablaBaya 7	--
77	Chekere 3	RepiniqueHrd	Tres!	Gu Roll	TablaBaya 8	--
78	Clave!	RepiniqueSft	Quatro!	HuYinLuoH Mt	TablaBaya Ge	--
79	Claves Lo 2	Repique Open	Grito-Hahaha	HuYinLuoH Op	TablaBaya Ka	--
80	Conga Hi Mt	Repique Rim	Grito-Ahaha!	HuYinLuoL Mt	TablaBaya Na	--
81	Conga Hi Op	Repique Roll	Grito-Haahai	HuYinLuoL Op	TablaBaya Te	--
82	Conga Link	SambaBateria	Grito-Rrrrr!	Nao Bo	TablaBaya Ti	--
83	Conga Lo Mt	SambaWhistle	Tiquitito!	Xiao Bo	TablaBayaGin	--
C6 84	Conga Roll	Shaker 1	Grito-Oa Oa!	Asian Gong 5	TablaBayaSld	--
85	Conga Slap	Shaker 2	Grito-Eh Eh!	Shou Luo 1	TablaBayaTin	--
86	Conga Thumb	Shaker Long	Ama ya ahi!	Shou Luo 2	TablaBayaTun	--
87	CongaLoOp f	Shaker Short	Fuego!	Shu Ban 1	Udu Pot1 Acc	--
88	CongaLoOp mf	--	Hey Brazil	Shu Ban 2	Udu Pot1 Hi	--
89	Cowbell 1	--	--	Shu Gu	Udu Pot1 Lo	--
90	Cowbell 2	--	--	Shu Gu Rim	Udu Pot1 Slp	--
91	Cowbell 3	--	--	Tang Gu Mt	Udu Pot2 Lng	--
92	Cowbell Mt 1	--	--	Tang Gu Op	Udu Pot2 Mut	--
93	Cowbell Mt 2	--	--	BaliCym Cls	Udu Pot2 Sht	--
94	Cowbell Op 1	--	--	BaliCym Opn	--	--
95	Cowbell Op 2	--	--	Ceng Ceng	--	--
C7 96	--	--	--	Chenchen Cls	--	--
97	--	--	--	Chenchen Opn	--	--
98	--	--	--	Kopyak Mt	--	--
99	--	--	--	Kopyak Op	--	--
100	--	--	--	Finger Cym	--	--
101	--	--	--	Ramacymbal	--	--
102	--	--	--	Jaw Harp Opn	--	--
103	--	--	--	Jaw Harp Wow	--	--

* *On the RD series (with SRX slots)/MC-909/VR-760/G-70/E-80, you can not select only the rhythm sets which are designed to be used with the Fantom series/ XV series/JUNO-G/MX-200.*

* *On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).*

※ SRX 対応の RD シリーズ /MC-909/VR-760 では、Fantom シリーズ / XV シリーズ /JUNO-G/MX-200 専用のリズム・セットを選ぶことはできません。

※ MC-909 では、Note No. 35（B1）から 50（D3）までの 16 鍵分のリズム・トーンのみ使用できます。

Waveform List (1)

No.	Name		
1	World Tour		
2	Korean Ens		
3	Morocco Ens		
4	African Ens		
5	Asia Phrase		
6	122:GamelnP1		**
7	78:GamelnP2		**
8	78:Korea Ph		**
9	118:ChinaPh1		**
10	132:ChinaPh2		**
11	118:TablaByP		**
12	92:DholakPh		**
13	120:Dhol Ph		**
14	96:Salsa		**
15	116:Mariachi		**
16	96:Cumbia		**
17	192:LatinPt1		**
18	180:LatinPt2		**
19	96:Cng6/8 1		**
20	96:Cng6/8 2		**
21	144:CgBolero		**
22	168:CgChacha		**
23	88:CgCumbia		**
24	160:CgMambo		**
25	104:CgMriach		**
26	138:CgMarinr		**
27	126:CgWonwn		**
28	132:TmblPtn1		**
29	132:TmblPtn2		**
30	100:TmblPtn3		**
31	120:TmblPtn4		**
32	104:Shakin'		**
33	80:PndrPtn1		**
34	108:PndrPtn2		**
35	138:PndrPtn3		**
36	132:AgogoPtn		**
37	132:BotlePtn		**
38	104:BomboPtn		**
39	126:SurdoPt1		**
40	108:SurdoPt2		**
41	138:CaixaPtn		**
42	132:TambrmPt		**
43	108:RepnqPt1		**
44	144:RepnqPt2		**
45	Samba MENU		*
46	BnjoPhs Menu	#	*
47	120:Bnjo G	#	**
48	120:Bnjo A	#	**
49	120:Bnjo B	#	**
50	120:Bnjo Cm	#	**
51	120:Bnjo Cm+	#	**
52	120:Bnjo G-C	#	**
53	120:BnjoG-C+	#	**
54	EG Phs Menu1	#	*
55	95:EGtr1 G	#	**
56	95:EGtr1 C	#	**
57	95:EGtr1 D	#	**
58	95:EGtr2 G	#	**
59	95:EGtr2 D	#	**
60	EG Phs Menu2	#	*

No.	Name		
61	140:EGtr3 G+	#	**
62	140:EGtr3 G	#	**
63	140:EGtr3 C+	#	**
64	140:EGtr3 C	#	**
65	140:EGtr3 D+	#	**
66	140:EGtr3 D	#	**
67	PdlSteelMenu	#	*
68	120:PdSt1 C	#	**
69	120:PdSt1 D	#	**
70	120:PdSt1 G	#	**
71	140:PdSt2 D	#	**
72	140:PdSt2 D+	#	**
73	140:PdSt2 G	#	**
74	140:PdSt2 G+	#	**
75	E.Gtr Sus A	#	
76	E.Gtr Sus B	#	
77	E.Gtr Sus C	#	
78	Strat Rear A		
79	Strat Rear B		
80	Strat Rear C		
81	LP Clean A		
82	LP Clean B		
83	LP Clean C		
84	Tele Front A		
85	Tele Front B		
86	Tele Front C		
87	Tele Rear A		
88	Tele Rear B		
89	Tele Rear C		
90	335Pick A		
91	335Pick B		
92	335Pick C		
93	E.Gtr Mute A	#	
94	E.Gtr Mute B	#	
95	E.Gtr Mute C	#	
96	335Mute A		
97	335Mute B		
98	335Mute C		
99	PdlSteel 1 A	#	
100	PdlSteel 1 B	#	
101	PdlSteel 1 C	#	
102	PdlSteel 2 A		
103	PdlSteel 2 B		
104	PdlSteel 2 C		
105	PdlSteel 3 A		
106	PdlSteel 3 B		
107	PdlSteel 3 C		
108	RequintoGtrA		
109	RequintoGtrB		
110	RequintoGtrC		
111	Nylon Gtr 3A		
112	Nylon Gtr 3B		
113	Nylon Gtr 3C		
114	AcGtr Pick A	#	
115	AcGtr Pick B	#	
116	AcGtr Pick C	#	
117	AcGtr Fngr A	#	
118	AcGtr Fngr B	#	
119	AcGtr Fngr C	#	
120	Ac.Guitar A		

No.	Name		
121	Ac.Guitar B		
122	Ac.Guitar C		
123	Reso.Gtr 2 A	#	
124	Reso.Gtr 2 B	#	
125	Reso.Gtr 2 C	#	
126	Reso.Gtr 3pA		
127	Reso.Gtr 3pB		
128	Reso.Gtr 3pC		
129	Reso.Gtr 3fA		
130	Reso.Gtr 3fB		
131	Reso.Gtr 3fC		
132	MandolinDn A	#	
133	MandolinDn B	#	
134	MandolinDn C	#	
135	MandolinUp A	#	
136	MandolinUp B	#	
137	MandolinUp C	#	
138	MandlnTrem A	#	
139	MandlnTrem B	#	
140	MandlnTrem C	#	
141	Banjo 2 A		
142	Banjo 2 B		
143	Banjo 2 C		
144	Banjo 3 A		
145	Banjo 3 B		
146	Banjo 3 C		
147	Bouzouki 2fA		
148	Bouzouki 2fB		
149	Bouzouki 2fC		
150	Bandolim		
151	Cavaquinho		
152	Oud A		
153	Oud B		
154	Oud C		
155	Sitar/Drone		
156	Sitar A		
157	Sitar B		
158	Sitar C		
159	Sitar 2 A		
160	Sitar 2 B		
161	Sitar 2 C		
162	SitarDrone		
163	Tambura A		
164	Tambura B		
165	Tambura C		
166	TamburaDrone		
167	Zither A		
168	Zither B		
169	Zither C		
170	Santur 2 A		
171	Santur 2 B		
172	Santur 2 C		
173	Santur Trm A		
174	Santur Trm B		
175	Santur Trm C		
176	HmrDulcimer		
177	Afro Zither		
178	Yuehchin		
179	Yangchin		
180	Yang Qin 2 A		

No.	Name		
181	Yang Qin 2 B		
182	Yang Qin 2 C		
183	YangQinTrm A		
184	YangQinTrm B		
185	YangQinTrm C		
186	Chung Ruan A		
187	Chung Ruan B		
188	Chung Ruan C		
189	Gu Zheng A		
190	Gu Zheng B		
191	Gu Zheng C		
192	Kanoun		
193	Koto		
194	Kayakeum		
195	Sanshin A		
196	Sanshin B		
197	Sanshin C		
198	Pi Pa A		
199	Pi Pa B		
200	Pi Pa C		
201	Biwa MENU		*
202	Biwa 1		
203	Biwa 2		
204	Biwa 3		
205	Shamisen 2		
206	Shami Attack		
207	BerimbauMENU		*
208	Berimbau Opn		
209	Berimbau Up		
210	Berimbau Dn		
211	Berimbau Mut		
212	Oct Harp		
213	Afro Harp		
214	JawHarp MENU		*
215	Jaw Harp Opn		
216	Jaw Harp Wow		
217	Gtr Strum 1		
218	Gtr Strum 2		
219	Nyln GtrNz 1		
220	Nyln GtrNz 2		
221	Guitarron Nz		
222	EG Bend Menu	#	*
223	EG C Bend 1	#	
224	EG C Bend 2	#	
225	EG D Bend 1	#	
226	EG D Bend 2	#	
227	EG D Bend 3	#	
228	EG E Bend 1	#	
229	EG E Bend 2	#	
230	EG E Bend 3	#	
231	EG SlideMenu	#	*
232	EG Slide 1	#	
233	EG Slide 2	#	
234	EG Slide 3	#	
235	EG Slide 4	#	
236	EG Slide 5	#	
237	EG Slide 6	#	
238	EG Slide 7	#	
239	EG Fx Menu	#	*
240	EG Rake 1	#	

Waveform List (2)

No.	Name	
241	EG Rake 2	
242	EG Mute	
243	BzkiChd Menu	*
244	Bouzki Chd 1	
245	Bouzki Chd 2	
246	Bouzki Chd 3	
247	Sitar Gliss	
248	GuZhengArpUp	
249	GuZhengArpDn	
250	Baby Bass ff	
251	6Str Bass A	
252	6Str Bass B	
253	6Str Bass C	
254	FingerdBs 2A	
255	FingerdBs 2B	
256	FingerdBs 2C	
257	Pick Bass 2	
258	6StBs Mute A	
259	6StBs Mute B	
260	6StBs Mute C	
261	Tub Bass	
262	Guitarron	
263	GuitarronOct	
264	Baby Bass Nz	
265	Violin 2 A	
266	Violin 2 B	
267	Violin 2 C	
268	Fiddle 1 A	
269	Fiddle 1 B	
270	Fiddle 1 C	
271	Fiddle 2 A	
272	Fiddle 2 B	
273	Fiddle 2 C	
274	Fdl Pizz 1 A	
275	Fdl Pizz 1 B	
276	Fdl Pizz 1 C	
277	Fdl Stac 1 A	
278	Fdl Stac 1 B	
279	Fdl Stac 1 C	
280	Erhu	
281	Er Hu 2 A	
282	Er Hu 2 B	
283	Er Hu 2 C	
284	Esraj 1	
285	Esraj 2	
286	Kemanche	
287	FiddleFxMenu	*
288	Fdl 5th 1	
289	Fdl 5th 2	
290	Fdl Riff 6	
291	Fdl Riff 8	
292	Er Hu Phrase	
293	Trumpets f A	
294	Trumpets f B	
295	Trumpets f C	
296	Tp Ambient A	
297	Tp Ambient B	
298	Tp Ambient C	
299	SoloTp Vib1A	
300	SoloTp Vib1B	
301	SoloTp Vib1C	
302	SoloTp Vib2A	
303	SoloTp Vib2B	
304	SoloTp Vib2C	
305	Tp RomanticA	
306	Tp RomanticB	
307	Tp RomanticC	
308	Tp Vib MariA	
309	Tp Vib MariB	
310	Tp Vib MariC	
311	Tp Shake A	
312	Tp Shake B	
313	Tp Shake C	
314	Tp Grrwah A	
315	Tp Grrwah B	
316	Tp Grrwah C	
317	MuteTp 2 A	
318	MuteTp 2 B	
319	MuteTp 2 C	
320	Tbns ff A	
321	Tbns ff B	
322	Tbns ff C	
323	Fat Tbns A	
324	Fat Tbns B	
325	Fat Tbns C	
326	Tbn Accent A	
327	Tbn Accent B	
328	Tbn Accent C	
329	Trombone3mfA	
330	Trombone3mfB	
331	Trombone3mfC	
332	Trombone3 fA	
333	Trombone3 fB	
334	Trombone3 fC	
335	Tbn Alto A	
336	Tbn Alto B	
337	Tbn Alto C	
338	Tuba f A	
339	Tuba f B	
340	Tuba f C	
341	2Tp+Tbn A	
342	2Tp+Tbn B	
343	2Tp+Tbn C	
344	2Tp+TbAltTnA	
345	2Tp+TbAltTnB	
346	2Tp+TbAltTnC	
347	Sect Fall A	
348	Sect Fall B	
349	Sect Fall C	
350	Sect Stact A	
351	Sect Stact B	
352	Sect Stact C	
353	SectChd 13th	
354	SectChd m9	
355	SectChd Mj9	
356	IndFlute L A	
357	IndFlute L B	
358	IndFlute L C	
359	IndFlute H A	
360	IndFlute H B	
361	IndFlute H C	
362	Bang Di A	
363	Bang Di B	
364	Bang Di C	
365	BangDi Vib A	
366	BangDi Vib B	
367	BangDi Vib C	
368	Qu Di A	
369	Qu Di B	
370	Qu Di C	
371	Qu Di Vib A	
372	Qu Di Vib B	
373	Qu Di Vib C	
374	Zampona 1	
375	Zampo Attack	
376	Zampo Trem A	
377	Zampo Trem B	
378	Zampo Trem C	
379	Sicu Pipe	
380	Quena	
381	Ocarina	
382	Kawala A	
383	Kawala B	
384	Kawala C	
385	Shakuhachi 2	
386	Shaku Attack	
387	Shaku Ornam	
388	Hunt Pipe	
389	Hunt Noise	
390	Bagpipes 1	
391	Bagpipes 2	
392	Bagpipes 3	
393	Bagpipes 4	
394	Hichiriki	
395	Hichiriki Lp	
396	Sheng A	
397	Sheng B	
398	Sheng C	
399	Suona A	
400	Suona B	
401	Suona C	
402	Shahnai	
403	Mizmar	
404	Mizmar Lp	
405	Piri	
406	Piri Lp	
407	Conch Shell1	
408	Conch Shell2	
409	Didge MENU	*
410	Didgeridoo 1	
411	Didgeridoo 2	
412	Didgeridoo 3	
413	Accrd ff OpA	
414	Accrd ff OpB	
415	Accrd ff OpC	
416	Accrd Cls A	
417	Accrd Cls B	
418	Accrd Cls C	
419	Musette 4 A	
420	Musette 4 B	
421	Musette 4 C	
422	D.AccordionA	
423	D.AccordionB	
424	D.AccordionC	
425	Harmonica2 A	
426	Harmonica2 B	
427	Harmonica2 C	
428	Harmonica3 A	
429	Harmonica3 B	
430	Harmonica3 C	
431	Harmonica4 A	
432	Harmonica4 B	
433	Harmonica4 C	
434	Voice MENU 1	*
435	Yoh Tribe	
436	How Tribe	
437	Hey Brazil	
438	Yyoo Dude	
439	ZaghrutaLoop	
440	ZaghrutaStop	
441	Bull Scream	
442	Voice MENU 2	*
443	Sabor!	
444	Arriba!	
445	Ole!	
446	Uno!	
447	Dos!	
448	Tres!	
449	Quatro!	
450	Grito-Hahaha	
451	Grito-Ahaha!	
452	Grito-Haahai	
453	Grito-Rrrrr!	
454	Voice MENU 3	*
455	Tiquitito!	
456	Grito-Oa Oa!	
457	Grito-Eh Eh!	
458	Ama ya ahi!	
459	Fuego!	
460	SambaBateria	
461	AsiaGng MENU	*
462	Asian Gong 1	
463	Asian Gong 2	
464	Asian Gong 3	
465	Asian Gong 4	
466	Asian Gong 5	
467	Asian Gong 6	
468	Asian Gong 7	
469	REV Gong 5	
470	REV Gong 7	
471	Gong MENU	*
472	Gamelan Gong	
473	Kempur	
474	Kajar	
475	Kelontuk	
476	Kelontuk Mt	
477	Kelontuk Sid	
478	Kemong	
479	Ceng Ceng	
480	Kopyak Op	

Waveform List (3)

No.	Name	
481	Kopyak Mt	
482	Kane	
483	Kane Side	
484	Korea MENU	*
485	Ching Open	
486	Ching Mute	
487	Kwaengwari p	
488	Kwaengwari f	
489	KwaengwariMt	
490	Bonang	
491	Spokes	
492	Satellite Dr	
493	Atarigane	
494	China MENU	*
495	Xiao Bo	
496	Nao Bo	
497	Shou Luo 1	
498	Shou Luo 2	
499	HuYinLuoL Op	
500	HuYinLuoL Mt	
501	HuYinLuoH Op	
502	HuYinLuoH Mt	
503	Ban Gu 1	
504	Ban Gu 2	
505	Ban Gu 3	
506	Gender	
507	Saron	
508	Jegogan A	
509	Jegogan B	
510	Jegogan C	
511	Jublag A	
512	Jublag B	
513	Jublag C	
514	Pemade A	
515	Pemade B	
516	Pemade C	
517	Reyong A	
518	Reyong B	
519	Reyong C	
520	Reyong Sid A	
521	Reyong Sid B	
522	Reyong Sid C	
523	Steel Dr 2	
524	Kalimba 1	
525	Kalimba 2	
526	Kalimba 3	
527	Kalimba Glis	
528	Kalim Gls Lp	
529	Balaphone 1	
530	Balaphone 2	
531	AsiaCym MENU	*
532	Chenchen Ptn	
533	Chenchen Opn	
534	Chenchen Cls	
535	BaliCym Opn	
536	BaliCym Cls	
537	Finger Cym	
538	Ramacymbal	
539	Sagat Open	
540	Sagat Close	

No.	Name	
541	Sarna Bell	
542	Wind Bell	
543	Blossom Bell	
544	Agogo MENU	*
545	Agogo 2 Lo	
546	Agogo 2 Hi	
547	Agogo 3 Lo	
548	Agogo 3 Hi	
549	AggoCwblMenu	*
550	BongoBell Op	
551	BongoBell Mt	
552	MamboBell Op	
553	MamboBell Mt	
554	Cowbell 1	
555	Cowbell 2	
556	Cowbell 3	
557	VDrm Cowbell	
558	Cowbell Op 1	
559	Cowbell Mt 1	
560	Cowbell Op 2	
561	Cowbell Mt 2	
562	TablaByMENU1	*
563	TablaBaya 1	
564	TablaBaya 2	
565	TablaBaya 3	
566	TablaBaya 4	
567	TablaBaya 5	
568	TablaBaya 6	
569	TablaBaya 7	
570	TablaBaya 8	
571	TablaByMENU2	*
572	TablaBayaSld	
573	TablaBayaGin	
574	TablaBaya Ge	
575	TablaBaya Ka	
576	TablaBaya Na	
577	TablaBayaTin	
578	TablaBayaTun	
579	TablaBaya Te	
580	TablaBaya Ti	
581	Dholak MENU1	*
582	Dholak 1	
583	Dholak 2	
584	Dholak 3	
585	Dholak 4	
586	Dholak 5	
587	Dholak 6	
588	Dholak 7	
589	Dholak 8	
590	Dholak 9	
591	Dholak MENU2	*
592	Dholak Ga	
593	Dholak Ta	
594	Dholak Tun	
595	Dholak Na	
596	Madal MENU	*
597	Madal Da	
598	Madal Din	
599	Madal Ta	
600	Dhol MENU	*

No.	Name	
601	Dhol 1	
602	Dhol 2	
603	Dhol 3	
604	Dhol 4	
605	Dhol 5	
606	Udu Pot MENU	*
607	Udu Pot1 Lo	
608	Udu Pot1 Hi	
609	Udu Pot1 Slp	
610	Udu Pot1 Acc	
611	Udu Pot2 Lng	
612	Udu Pot2 Sht	
613	Udu Pot2 Mut	
614	Kendang MENU	*
615	Wadon 1	
616	Wadon 2	
617	Wadon 3	
618	Wadon 4	
619	Wadon 5	
620	Wadon 6	
621	Wadon 7	
622	Bebarongan 1	
623	Bebarongan 2	
624	Bebarongan 3	
625	Pelegongan 1	
626	Pelegongan 2	
627	Pelegongan 3	
628	TalkingDr Up	
629	TalkingDr Dn	
630	AfroDrm MENU	*
631	AfroDrum Op1	
632	AfroDrum Op2	
633	AfroDrum Flm	
634	AfroDrum Rat	
635	Tablah MENU	*
636	Tablah Bend	
637	Tablah Dom	
638	Tablah Tak	
639	Tablah Rim	
640	Tablah Roll	
641	Doira Dun	
642	Doira Tik	
643	Doholla MENU	*
644	Doholla Dom	
645	Doholla Sak	
646	Doholla Tak	
647	Doholla Roll	
648	Doholla Stop	
649	Rek MENU	*
650	Rek Dom	
651	Rek Tek	
652	Rek Open	
653	Rek Trill	
654	Bendir 1	
655	Bendir 2	
656	Dawul	
657	JapanPrcMENU	*
658	Japan MENU	*
659	Ho	
660	Yoh	

No.	Name	
661	iYooh	
662	Taiko	
663	Wadaiko	
664	Wadaiko Rim	
665	Sime Taiko	
666	Shimedaiko 2	
667	Buk	
668	Buk Rim	
669	Tsuzumi Lo	
670	Tsuzumi Hi	
671	Tsuzumi 2 p	
672	Tsuzumi 2 mf	
673	Tsuzumi 2 Hi	
674	Mokugyo 1	
675	Mokugyo 2	
676	Ohkawa	
677	Ohkawa 2	
678	Hyoshigi	
679	Hyoshigi 2	
680	Clapstick	
681	VDrm Woodblk	
682	Boomerang	
683	Changgo	
684	Tang Gu Op	
685	Tang Gu Mt	
686	Shu Gu	
687	Shu Gu Rim	
688	Shu Ban 1	
689	Shu Ban 2	
690	Ban Gu 4	
691	ChinaPrcMENU	*
692	Gu Roll	
693	Gu Hi	
694	Rot Drum	
695	Log Drum 2	
696	Slit Drum	
697	Bongo MENU 1	*
698	Bongo 1 Lo	
699	Bongo 1 Hi	
700	Bongo 2 Lo	
701	Bongo 2 Hi	
702	Bongo MENU 2	*
703	Bongo LoOp f	
704	Bongo Lo Hrd	
705	Bongo Lo Sft	
706	Bongo LoOpmf	
707	Bongo LoSlap	
708	Bongo Hi Hrd	
709	Bongo HiOp f	
710	BongoHiSlap1	
711	BongoHiSlap2	
712	Conga Menu	*
713	CongaLoOp f	
714	CongaLoOp mf	
715	Conga Lo Mt	
716	Conga Slap	
717	Conga Hi Op	
718	Conga Hi Mt	
719	Conga Thumb	
720	Conga Link	

Waveform List (4)

No.	Name	
721	Conga Roll	
722	Timbale MENU	*
723	Timbale Lo	
724	Timbale Hi	
725	Timbale Side	
726	TimbalesMenu	*
727	Timbles LoOp	
728	Timbles LoMt	
729	Timbles HiOp	
730	Timbles HiMt	
731	TimbalesHand	
732	Timbales Rim	
733	TmbSideStick	
734	TimbalesFil1	
735	TimbalesFil2	
736	TimbalesFil3	
737	TimbalesFil4	
738	Surdo MENU 1	*
739	Surdo Open L	
740	Surdo Open H	
741	Surdo Mute	
742	Surdo Rim	
743	Surdo MENU 2	*
744	Surdo Hard	
745	Surdo Open1	
746	Surdo Open2	
747	Surdo Mute2	
748	Surdo Rim 2	
749	Surdo Soft	
750	Caixa MENU 1	*
751	Caixa Open1	
752	Caixa Open2	
753	Caixa Roll	
754	Caixa Mute	
755	Caixa MENU 2	*
756	Caixa Open3	
757	Caixa Mute2	
758	Caixa Roll2	
759	Caixa Rim	
760	Rpnq&RpqMenu	*
761	RepiniqueHrd	
762	RepiniqueSft	
763	Repinique1	
764	Repinique2	
765	Repique Open	
766	Repique Rim	
767	Repique Roll	
768	Clv&CucaMenu	*
769	Clave!	
770	Claves Lo 2	
771	VDrm Claves	
772	Cuica 2	
773	Cuica 3	
774	Cuica Lo 1	
775	Cuica Lo 2	
776	Cuica Hi 1	
777	Cuica Hi 2	
778	MrcsShkrMenu	*
779	Maracas 2	
780	MaracasUpDwn	
781	VDrm Maracas	
782	Shaker MENU	*
783	Shaker Ptn	
784	Shaker 1	
785	Shaker 2	
786	Shaker Long	
787	Shaker Short	
788	Angklung 2	
789	Rainstick	
790	Guiro Long	
791	Guiro Short	
792	Guiro Menu	*
793	Quide Long	
794	Quide Short	
795	Guiro Long2	
796	Guiro Short2	
797	RecoRecoLng	
798	RecoRecoSht	
799	MtlGuiroLng	
800	MtlGuiroSht	
801	CbsCxGnzMenu	*
802	Real Cabasa1	
803	Real Cabasa2	
804	Cabasa Roll	
805	VDrmCabasaUp	
806	VDrmCabasDwn	
807	Caxixi	
808	Ganza Soft	
809	Ganza Hard	
810	Chekere 1	
811	Chekere 2	
812	PandeiroMENU	*
813	PandeiroL Lo	
814	PandeiroL Hi	
815	PandeiroL Sp	
816	PandeiroL Rm	
817	PandeiroS Op	
818	PandeiroS Sp	
819	PandeiroS Rm	
820	PandTambMenu	*
821	PandeiroOpen	
822	PandeiroMute	
823	PandeiroHit	
824	PandeiroRim	
825	PandeiroCrsh	
826	PandeiroRoll	
827	TamborimMENU	*
828	Tamborim Opn	
829	Tamborim Mut	
830	Tamborim Slp	
831	TamborimOpen	
832	TamborimRim	
833	TamborimMute	
834	TamborimRoll	
835	Tambrin Hit	
836	TambrinShake	
837	R8 Tamb	
838	Others Menu	*
839	ApitoHiShort	
840	ApitoLoShort	
841	SambaWhistle	
842	Quijada	
843	Chekere 3	
844	CajonClpMenu	*
845	Cajon Lo	
846	Cajon Hi	
847	Cajon Rol Hi	
848	Cajon Rol Lo	
849	Afro Feet 1	
850	Afro Feet 2	
851	Afro Clap	
852	Hand Clap 2	
853	Claps Real	
854	FingerSnaps4	
855	BomboBbnMenu	*
856	SoftSet Menu	*
857	HardSet Menu	*
858	Fat BD	
859	Room Kick 2	
860	Maple Kick	
861	Warm Kick	
862	Maple Lo Snr	
863	MapleSoft SN	
864	NaturlHardSN	
865	NaturlRimSht	
866	Cross Stick2	
867	StudioLo Tom	
868	StudioMidTom	
869	StudioHi Tom	
870	Dixie HH Pdl	
871	Dixie HH Cls	
872	Dixie HH Hlf	
873	Dixie HH Opn	

*: These are menu waveforms. Include multiple waveforms assigned to keys individually.

**: These are the phrase loop waveforms. The numbers included in the wave name represent the recommended tempo (B.P.M.). And these waveforms can be synchronized to a device such as a sequencer.

#: This waveform was selected from the CD-ROM "Whole Lotta Country" from Sampleheads.

When you create a Patch using the waveforms stored in the Expansion Board, observe the following points:

* *If you make a Patch with a single voice and then later play it in a chord, the sound may be distorted with certain settings for the Effects and TVA. If this happens, adjust the level of the Effects and TVA.*

* *This product uses waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.*

＊： メニュー・ウェーブフォームです。複数のウェーブフォームが、各キーに割り当てられています。

＊＊： フレーズ・ループのウェーブフォームです。ウェーブ・ネームに付いている数字は推奨テンポ（B.P.M.）です。また、これらのウェーブフォームはシーケンサー等との同期が可能です。

＃： このウェーブフォームは Sampleheads 社 CD-ROM「WHOLE Lotta Country」からセレクトされています。

このエクスパンション・ボードに収められているウェーブフォームを使ってパッチを作るときには、次の点に注意してください。

※ 単音でパッチを作ったとき、エフェクトや TVA の設定状態によって、その音を和音で演奏すると音が歪む場合があります。このようなときは、エフェクトや TVA のレベルを調整してください。

※ 本製品のウェーブフォームは SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。

Waveform List (1) (By Region 地域別)

India (インド)

No.	Name
156	Sitar A
157	Sitar B
158	Sitar C
159	Sitar 2 A
160	Sitar 2 B
161	Sitar 2 C
247	Sitar Gliss
162	SitarDrone
155	Sitar/Drone
170	Santur 2 A
171	Santur 2 B
172	Santur 2 C
173	Santur Trm A
174	Santur Trm B
175	Santur Trm C
163	Tambura A
164	Tambura B
165	Tambura C
166	TamburaDrone
284	Esraj 1
285	Esraj 2
402	Shahnai
356	IndFlute L A
357	IndFlute L B
358	IndFlute L C
359	IndFlute H A
360	IndFlute H B
361	IndFlute H C
541	Sarna Bell
11	118:TablaByP
571	TablaBYMENU2
572	TablaBayaSld
573	TablaBayaGin
574	TablaBaya Ge
575	TablaBaya Ka
576	TablaBaya Na
577	TablaBayaTin
578	TablaBayaTun
579	TablaBaya Te
580	TablaBaya Ti
562	TablaByMENU1
563	TablaBaya 1
564	TablaBaya 2
565	TablaBaya 3
566	TablaBaya 4
567	TablaBaya 5
568	TablaBaya 6
569	TablaBaya 7
570	TablaBaya 8
606	Udu Pot MENU
607	Udu Pot1 Lo
608	Udu Pot1 Hi
609	Udu Pot1 Slp
610	Udu Pot1 Acc
611	Udu Pot2 Lng
612	Udu Pot2 Sht
613	Udu Pot2 Mut
12	92:DholakPh
591	Dholak MENU1
592	Dholak Ga
593	Dholak Ta
594	Dholak Tun
595	Dholak Na
581	Dholak MENU2
582	Dholak 1
583	Dholak 2
584	Dholak 3
585	Dholak 4
586	Dholak 5
587	Dholak 6
588	Dholak 7
589	Dholak 8
590	Dholak 9
13	120:Dhol Ph
600	Dhol MENU
601	Dhol 1
602	Dhol 2
603	Dhol 3
604	Dhol 4
605	Dhol 5
596	Madal MENU
597	Madal Da
598	Madal Din
599	Madal Ta

Middle East (中近東)

No.	Name
152	Oud A
153	Oud B
154	Oud C
286	Kemanche
382	Kawala A
383	Kawala B
384	Kawala C
403	Mizmar
404	Mizmar Lp
404	Mizmar Lp
539	Sagat Open
540	Sagat Close
635	Tablah MENU
636	Tablah Bend
637	Tablah Dom
638	Tablah Tak
639	Tablah Rim
640	Tablah Roll
641	Doira Dun
642	Doira Tik
643	Doholla MENU
644	Doholla Dom
645	Doholla Sak
646	Doholla Tak
647	Doholla Roll
648	Doholla Stop
649	Rek MENU
650	Rek Dom
651	Rek Tek
652	Rek Open
653	Rek Trill
654	Bendir 1
655	Bendir 2
656	Dawul
439	ZaghrutaLoop
440	ZaghrutaStop
3	Morocco Ens

Japan (日本)

No.	Name
193	Koto
205	Shamisen 2
206	Shami Attack
201	Biwa MENU
202	Biwa 1
203	Biwa 2
204	Biwa 3
385	Shakuhachi 2
386	Shaku Attack
387	Shaku Ornam
394	Hichiriki
395	Hichiriki Lp
493	Atarigane
678	Hyoshigi
657	JapanPrcMENU
662	Taiko
665	Sime Taiko
669	Tsuzumi Lo
670	Tsuzumi Hi
676	Ohkawa
438	Yyoo Dude
195	Sanshin A
196	Sanshin B
197	Sanshin C
482	Kane
483	Kane Side
542	Wind Bell
658	Japan MENU
663	Wadaiko
664	Wadaiko Rim
666	Shimedaiko 2
671	Tsuzumi 2 p
672	Tsuzumi 2 mf
673	Tsuzumi 2 Hi
677	Ohkawa 2
674	Mokugyo 1
675	Mokugyo 2
679	Hyoshigi 2
659	Ho
660	Yoh
661	iYooh

Korea (韓国)

No.	Name
194	Kayakeum
405	Piri
406	Piri Lp
484	Korea MENU
485	Ching Open
486	Ching Mute
487	Kwaengwari p
488	Kwaengwari f
489	KwaengwariMt
667	Buk
668	Buk Rim
683	Changgo
8	78:Korea Ph
2	Korean Ens

China (中国)

No.	Name
178	Yuehchin
179	Yangchin
280	Erhu
461	AsiaGng MENU
462	Asian Gong 1
463	Asian Gong 2
464	Asian Gong 3
465	Asian Gong 4
466	Asian Gong 5
467	Asian Gong 6
468	Asian Gong 7
469	REV Gong 5
470	REV Gong 7
531	AsiaCym MENU
503	Ban Gu 1
504	Ban Gu 2
505	Ban Gu 3
691	ChinaPrcMENU
692	Gu Roll
693	Gu Hi
198	Pi Pa A
199	Pi Pa B
200	Pi Pa C
186	Chung Ruan A
187	Chung Ruan B
188	Chung Ruan C
189	Gu Zheng A
190	Gu Zheng B
191	Gu Zheng C
180	Yang Qin 2 A
181	Yang Qin 2 B
182	Yang Qin 2 C
183	YangQinTrm A
184	YangQinTrm B
185	YangQinTrm C
281	Er Hu 2 A
282	Er Hu 2 B
283	Er Hu 2 C
362	Bang Di A
363	Bang Di B
364	Bang Di C
365	BangDi Vib A
366	BangDi Vib B
367	BangDi Vib C
368	Qu Di A
369	Qu Di B
370	Qu Di C
371	Qu Di Vib A
372	Qu Di Vib B
373	Qu Di Vib C
396	Sheng A
397	Sheng B
398	Sheng C
399	Suona A
400	Suona B
401	Suona C
494	China MENU
495	Xiao Bo
496	Nao Bo
497	Shou Luo 1
498	Shou Luo 2
499	HuYinLuoL Op

Waveform List (2) (By Region 地域別)

500	HuYinLuoL Mt
501	HuYinLuoH Op
502	HuYinLuoH Mt
684	Tang Gu Op
685	Tang Gu Mt
686	Shu Gu
687	Shu Gu Rim
687	Shu Gu Rim
688	Shu Ban 1
689	Shu Ban 2
292	Er Hu Phrase
248	GuZhengArpUp
249	GuZhengArpDn
9	118:ChinaPh1
10	132:ChinaPh2

Europe (ヨーロッパ)

No.	Name
167	Zither A
168	Zither B
169	Zither C
381	Ocarina
390	Bagpipes 1
391	Bagpipes 2
392	Bagpipes 3
393	Bagpipes 4

North America (北米)

No.	Name
176	HmrDulcimer

South America (南米)

No.	Name
150	Bandolim
151	Cavaquinho
212	Oct Harp
374	Zampona 1
375	Zampo Attack
376	Zampo Trem A
377	Zampo Trem B
378	Zampo Trem C
379	Sicu Pipe
380	Quena
523	Steel Dr 2
207	BerimbauMENU
208	Berimbau Opn
209	Berimbau Up
210	Berimbau Dn
211	Berimbau Mut
789	Rainstick
437	Hey Brazil
45	Samba MENU
460	SambaBateria
812	PandeiroMENU
813	PandeiroL Lo
814	PandeiroL Hi
815	PandeiroL Sp
816	PandeiroL Rm
817	PandeiroS Op
818	PandeiroS Sp
819	PandeiroS Rm
827	TamborimMENU
828	Tamborim Opn
829	Tamborim Mut
830	Tamborim Slp
738	Surdo MENU 1
743	Surdo MENU 2
739	Surdo Open L
740	Surdo Open H
741	Surdo Mute
747	Surdo Mute2
742	Surdo Rim
748	Surdo Rim 2
750	Caixa MENU 1
755	Caixa MENU 2
751	Caixa Open1
752	Caixa Open2
753	Caixa Roll
758	Caixa Roll2
754	Caixa Mute
757	Caixa Mute2
544	Agogo MENU
545	Agogo 2 Lo
546	Agogo 2 Hi
547	Agogo 3 Lo
548	Agogo 3 Hi
554	Cowbell 1
555	Cowbell 2
556	Cowbell 3
772	Cuica 2
773	Cuica 3
782	Shaker MENU
783	Shaker Ptn
784	Shaker 1
785	Shaker 2
810	Chekere 1
811	Chekere 2
841	SambaWhistle
790	Guiro Long
795	Guiro Long2
791	Guiro Short
796	Guiro Short2
722	Timbale MENU
723	Timbale Lo
724	Timbale Hi
725	Timbale Side
697	Bongo MENU 1
702	Bongo MENU 2
698	Bongo 1 Lo
699	Bongo 1 Hi
700	Bongo 2 Lo
701	Bongo 2 Hi

Africa (アフリカ)

No.	Name
213	Afro Harp
388	Hunt Pipe
389	Hunt Noise
524	Kalimba 1
525	Kalimba 2
526	Kalimba 3
527	Kalimba Glis
528	Kalim Gls Lp
529	Balaphone 1
530	Balaphone 2
695	Log Drum 2
696	Slit Drum
628	TalkingDr Up
629	TalkingDr Dn
630	AfroDrm MENU
631	AfroDrum Op1
632	AfroDrum Op2
633	AfroDrum Flm
634	AfroDrum Rat
177	Afro Zither
849	Afro Feet 1
850	Afro Feet 2
851	Afro Clap
435	Yoh Tribe
436	How Tribe
4	African Ens

Southeast Asia (東南アジア)

No.	Name
490	Bonang
506	Gender
507	Saron
537	Finger Cym
538	Ramacymbal
532	Chenchen Ptn
533	Chenchen Opn
534	Chenchen Cls
535	BaliCym Opn
536	BaliCym Cls
788	Angklung 2
214	JawHarp MENU
215	Jaw Harp Opn
216	Jaw Harp Wow

Australia (オーストラリア)

No.	Name
680	Clapstick
682	Boomerang
409	Didge MENU
410	Didgeridoo 1
411	Didgeridoo 2
412	Didgeridoo 3

Others (その他)

No.	Name
543	Blossom Bell
491	Spokes
694	Rot Drum
434	Voice MENU 1
442	Voice MENU 2
454	Voice MENU 3
441	Bull Scream
407	Conch Shell1
408	Conch Shell2
1	World Tour

Menu Waveform (1)

45 Samba MENU

Key	Wave#	WaveName	
C 4		Samba Phr1	*
D 4		Samba Phr2	*
E 4		Samba Phr3	*

46 BnjoPhs Menu

Key	Wave#	WaveName
C 4	47	120:Bnjo G
D 4	48	120:Bnjo A
E 4	49	120:Bnjo B
F 4	50	120:Bnjo Cm
G 4	51	120:Bnjo Cm+
A 4	52	120:Bnjo G-C
B 4	53	120:BnjoG-C+

54 EG Phs Menu1

Key	Wave#	WaveName
C 4	55	95:EGtr1 G
D 4	56	95:EGtr1 C
E 4	57	95:EGtr1 D
F 4	58	95:EGtr2 G
G 4	59	95:EGtr2 D

60 EG Phs Menu2

Key	Wave#	WaveName
C 4	61	140:EGtr3 G+
D 4	62	140:EGtr3 G
E 4	63	140:EGtr3 C+
F 4	64	140:EGtr3 C
G 4	65	140:EGtr3 D+
A 4	66	140:EGtr3 D

67 PdlSteelMenu

Key	Wave#	WaveName
C 4	68	120:PdSt1 C
D 4	69	120:PdSt1 D
E 4	70	120:PdSt1 G
F 4	71	140:PdSt2 D
G 4	72	140:PdSt2 D+
A 4	73	140:PdSt2 G
B 4	74	140:PdSt2 G+

201 Biwa MENU

Key	Wave#	WaveName
C 4	202	Biwa 1
D 4	203	Biwa 2
E 4	204	Biwa 3

207 BerimbauMENU

Key	Wave#	WaveName
C 4	208	Berimbau Opn
D 4	209	Berimbau Up
E 4	210	Berimbau Dn
F 4	211	Berimbau Mut

214 JawHarp MENU

Key	Wave#	WaveName	
C 4	215	Jaw Harp Opn	
D 4	216	Jaw Harp Wow	
E 4		Reverse ?	*

222 EG Bend Menu

Key	Wave#	WaveName
C 4	223	EG C Bend 1
D 4	224	EG C Bend 2
E 4	225	EG D Bend 1
F 4	226	EG D Bend 2
G 4	227	EG D Bend 3
A 4	228	EG E Bend 1
B 4	229	EG E Bend 2
C 5	230	EG E Bend 3

231 EG SlideMenu

Key	Wave#	WaveName
C 4	232	EG Slide 1
D 4	233	EG Slide 2
E 4	234	EG Slide 3
F 4	235	EG Slide 4
G 4	236	EG Slide 5
A 4	237	EG Slide 6
B 4	238	EG Slide 7

239 EG Fx Menu

Key	Wave#	WaveName
C 4	240	EG Rake 1
D 4	241	EG Rake 2
E 4	242	EG Mute

243 BzkiChd Menu

Key	Wave#	WaveName
C 4	244	Bouzki Chd 1
D 4	244	Bouzki Chd 1
E 4	245	Bouzki Chd 2
F 4	245	Bouzki Chd 2
G 4	246	Bouzki Chd 3
A 4	246	Bouzki Chd 3

287 FiddleFxMenu

Key	Wave#	WaveName
C 4	288	Fdl 5th 1
D 4	289	Fdl 5th 2
E 4	290	Fdl Riff 6
F 4	291	Fdl Riff 8

409 Didge MENU

Key	Wave#	WaveName	
C 4	410	Didgeridoo 1	
D 4	411	Didgeridoo 2	
E 4	412	Didgeridoo 3	
F 4		Didgeridoo 4	*
G 4		Didgeridoo 5	*
A 4		Didgeridoo 6	*

434 Voice MENU 1

Key	Wave#	WaveName
C 4	435	Yoh Tribe
D 4	436	How Tribe
E 4	437	Hey Brazil
F 4	438	Yyoo Dude
G 4	439	ZaghrutaLoop
A 4	440	ZaghrutaStop
B 4	441	Bull Scream

442 Voice MENU 2

Key	Wave#	WaveName
C 4	443	Sabor!
D 4	444	Arriba!
E 4	445	Ole!
F 4	446	Uno!
G 4	447	Dos!
A 4	448	Tres!
B 4	449	Quatro!
C 5	450	Grito-Hahaha
D 5	451	Grito-Ahaha!
E 5	452	Grito-Haahai
F 5	453	Grito-Rrrrr!

454 Voice MENU 3

Key	Wave#	WaveName
C 4	455	Tiquitito!
D 4	456	Grito-Oa Oa!
E 4	457	Grito-Eh Eh!
F 4	458	Ama ya ahi!
G 4	459	Fuego!

461 AsiaGng MENU

Key	Wave#	WaveName	
C 4	462	Asian Gong 1	
D 4	463	Asian Gong 2	
E 4	464	Asian Gong 3	
F 4	465	Asian Gong 4	
G 4	466	Asian Gong 5	
A 4	467	Asian Gong 6	
B 4	468	Asian Gong 7	
C 5		REV Gong 4	*
D 5		REV Gong 5	*
E 5		REV Gong 6	*
F 5		REV Gong 7	*

471 Gong MENU

Key	Wave#	WaveName
C 4	472	Gamelan Gong
D 4	473	Kempur
E 4	474	Kajar
F 4	475	Kelontuk
G 4	476	Kelontuk Mt
A 4	477	Kelontuk Sid
B 4	478	Kemong
C 5	479	Ceng Ceng
D 5	480	Kopyak Op
E 5	481	Kopyak Mt
F 5	6	122:GamelnP1
G 5	7	78:GamelnP2

484 Korea MENU

Key	Wave#	WaveName
C 4	667	Buk
D 4	668	Buk Rim
E 4	683	Changgo
F 4	485	Ching Open
G 4	486	Ching Mute
A 4	487	Kwaengwari p
B 4	488	Kwaengwari f
C 5	489	KwaengwariMt

494 China MENU

Key	Wave#	WaveName
C 4	684	Tang Gu Op
D 4	685	Tang Gu Mt
E 4	686	Shu Gu
F 4	687	Shu Gu Rim
G 4	688	Shu Ban 1
A 4	689	Shu Ban 2
B 4	690	Ban Gu 4
C 5	495	Xiao Bo
D 5	496	Nao Bo
E 5	497	Shou Luo 1
F 5	498	Shou Luo 2
G 5	499	HuYinLuoL Op
A 5	500	HuYinLuoL Mt
B 5	501	HuYinLuoH Op
C 6	502	HuYinLuoH Mt
D 6	10	132:ChinaPh2

531 AsiaCym MENU

Key	Wave#	WaveName
C 4	532	Chenchen Ptn
D 4	533	Chenchen Opn
E 4	534	Chenchen Cls
F 4	535	BaliCym Opn
G 4	536	BaliCym Cls

544 Agogo MENU

Key	Wave#	WaveName
C 4	545	Agogo 2 Lo
D 4	546	Agogo 2 Hi
E 4	547	Agogo 3 Lo
F 4	548	Agogo 3 Hi
G 4	554	Cowbell 1
A 4	555	Cowbell 2
B 4	556	Cowbell 3

549 AggoCwblMenu

Key	Wave#	WaveName
C 4	550	BongoBell Op
D 4	551	BongoBell Mt
E 4	552	MamboBell Op
F 4	553	MamboBell Mt
G 4	558	Cowbell Op 1
A 4	559	Cowbell Mt 1
B 4	560	Cowbell Op 2
C 5	561	Cowbell Mt 2

562 TablaByMENU1

Key	Wave#	WaveName
C 4	563	TablaBaya 1
D 4	564	TablaBaya 2
E 4	565	TablaBaya 3
F 4	566	TablaBaya 4
G 4	567	TablaBaya 5
A 4	568	TablaBaya 6
B 4	569	TablaBaya 7
C 5	570	TablaBaya 8
D 5	11	118:TablaByP

Menu Waveform (2)

571 TablaByMENU2

Key	Wave#	WaveName	
C 4		TablaBayaP 1	*
D 4		TablaBayaP 2	*
E 4		TablaBayaP 3	*
F 4		TablaBayaP 4	*
G 4		TablaBayaP 5	*
A 4	572	TablaBayaSld	
B 4	573	TablaBayaGin	
C 5	574	TablaBaya Ge	
D 5	575	TablaBaya Ka	
E 5	576	TablaBaya Na	
F 5	577	TablaBayaTin	
G 5	578	TablaBayaTun	
A 5	579	TablaBaya Te	
B 5	580	TablaBaya Ti	

581 Dholak MENU1

Key	Wave#	WaveName
C 4	582	Dholak 1
D 4	583	Dholak 2
E 4	584	Dholak 3
F 4	585	Dholak 4
G 4	586	Dholak 5
A 4	587	Dholak 6
B 4	588	Dholak 7
C 5	589	Dholak 8
D 5	590	Dholak 9
E 5	12	92:DholakPh

591 Dholak MENU2

Key	Wave#	WaveName	
C 4	592	Dholak Ga	
D 4	593	Dholak Ta	
E 4	594	Dholak Tun	
F 4	595	Dholak Na	
G 4		Dholak Ga 2	*

596 Madal MENU

Key	Wave#	WaveName
C 4	597	Madal Da
D 4	598	Madal Din
E 4	599	Madal Ta

600 Dhol MENU

Key	Wave#	WaveName
C 4	601	Dhol 1
D 4	602	Dhol 2
E 4	603	Dhol 3
F 4	604	Dhol 4
G 4	605	Dhol 5
A 4	13	120:Dhol Ph

606 Udu Pot MENU

Key	Wave#	WaveName	
C 4		Udu Pot Phr1	*
D 4		Udu Pot Phr2	*
E 4		Udu Pot Phr3	*
F 4	607	Udu Pot1 Lo	
G 4	608	Udu Pot1 Hi	
A 4	609	Udu Pot1 Slp	
B 4	610	Udu Pot1 Acc	
C 5	611	Udu Pot2 Lng	
D 5	612	Udu Pot2 Sht	
E 5	613	Udu Pot2 Mut	

614 Kendang MENU

Key	Wave#	WaveName
C 4	615	Wadon 1
D 4	616	Wadon 2
E 4	617	Wadon 3
F 4	618	Wadon 4
G 4	619	Wadon 5
A 4	620	Wadon 6
B 4	621	Wadon 7
C 5	622	Bebarongan 1
D 5	623	Bebarongan 2
E 5	624	Bebarongan 3
F 5	625	Pelegongan 1
G 5	626	Pelegongan 2
A 5	627	Pelegongan 3

630 AfroDrm MENU

Key	Wave#	WaveName
C 4	631	AfroDrum Op1
D 4	632	AfroDrum Op2
E 4	633	AfroDrum Flm
F 4	634	AfroDrum Rat

635 Tablah MENU

Key	Wave#	WaveName	
C 4		Tablah Phr1	*
D 4		Tablah Phr2	*
E 4		Tablah Phr3	*
F 4		Tablah Phr4	*
G 4	636	Tablah Bend	
A 4	637	Tablah Dom	
B 4	638	Tablah Tak	
C 5	639	Tablah Rim	
D 5	640	Tablah Roll	

643 Doholla MENU

Key	Wave#	WaveName
C 4	644	Doholla Dom
D 4	645	Doholla Sak
E 4	646	Doholla Tak
F 4	647	Doholla Roll
G 4	648	Doholla Stop

649 Rek MENU

Key	Wave#	WaveName
C 4	650	Rek Dom
D 4	651	Rek Tek
E 4	652	Rek Open
F 4	653	Rek Trill

657 JapanPrcMENU

Key	Wave#	WaveName
C 4	662	Taiko
D 4	665	Sime Taiko
E 4	669	Tsuzumi Lo
F 4	670	Tsuzumi Hi
G 4	676	Ohkawa
A 4	678	Hyoshigi
B 4	493	Atarigane
C 5	438	Yyoo Dude

658 Japan MENU

Key	Wave#	WaveName
C 4	663	Wadaiko
D 4	664	Wadaiko Rim
E 4	666	Shimedaiko 2
F 4	671	Tsuzumi 2 p
G 4	672	Tsuzumi 2 mf
A 4	673	Tsuzumi 2 Hi
B 4	677	Ohkawa 2
C 5	674	Mokugyo 1
D 5	675	Mokugyo 2
E 5	679	Hyoshigi 2
F 5	482	Kane
G 5	483	Kane Side
A 5	542	Wind Bell
B 5	659	Ho
C 6	660	Yoh
D 6	661	iYooh

691 ChinaPrcMENU

Key	Wave#	WaveName
C 4	692	Gu Roll
D 4	693	Gu Hi
E 4	694	Rot Drum
F 4	695	Log Drum 2
G 4	696	Slit Drum
A 4	466	Asian Gong 5
B 4	467	Asian Gong 6
C 5	468	Asian Gong 7

697 Bongo MENU 1

Key	Wave#	WaveName
C 4	698	Bongo 1 Lo
D 4	699	Bongo 1 Hi
E 4	700	Bongo 2 Lo
F 4	701	Bongo 2 Hi

702 Bongo MENU 2

Key	Wave#	WaveName
C 4	703	Bongo LoOp f
D 4	704	Bongo Lo Hrd
E 4	705	Bongo Lo Sft
F 4	706	Bongo LoOpmf
G 4	707	Bongo LoSlap
A 4	708	Bongo Hi Hrd
B 4	709	Bongo HiOp f
C 5	710	BongoHiSlap1
D 5	711	BongoHiSlap2

712 Conga Menu

Key	Wave#	WaveName
C 4	713	CongaLoOp f
D 4	714	CongaLoOp mf
E 4	715	Conga Lo Mt
F 4	716	Conga Slap
G 4	717	Conga Hi Op
A 4	718	Conga Hi Mt
B 4	719	Conga Thumb
C 5	720	Conga Link
D 5	721	Conga Roll

722 Timbale MENU

Key	Wave#	WaveName
C 4	723	Timbale Lo
D 4	724	Timbale Hi
E 4	725	Timbale Side

726 TimbalesMenu

Key	Wave#	WaveName
C 4	727	Timbles LoOp
D 4	728	Timbles LoMt
E 4	729	Timbles HiOp
F 4	730	Timbles HiMt
G 4	731	TimbalesHand
A 4	732	Timbales Rim
B 4	733	TmbSideStick
C 5	734	TimbalesFil1
D 5	735	TimbalesFil2
E 5	736	TimbalesFil3
F 5	737	TimbalesFil4

738 Surdo MENU 1

Key	Wave#	WaveName
C 4	739	Surdo Open L
D 4	740	Surdo Open H
E 4	741	Surdo Mute
F 4	742	Surdo Rim

743 Surdo MENU 2

Key	Wave#	WaveName
C 4	744	Surdo Hard
D 4	745	Surdo Open1
E 4	746	Surdo Open2
F 4	747	Surdo Mute2
G 4	748	Surdo Rim 2
A 4	749	Surdo Soft

750 Caixa MENU 1

Key	Wave#	WaveName
C 4	751	Caixa Open1
D 4	752	Caixa Open2
E 4	753	Caixa Roll
F 4	754	Caixa Mute

755 Caixa MENU 2

Key	Wave#	WaveName
C 4	756	Caixa Open3
D 4	757	Caixa Mute2
E 4	758	Caixa Roll2
F 4	759	Caixa Rim

760 Rpnq&RpqMenu

Key	Wave#	WaveName
C 4	761	RepiniqueHrd
D 4	762	RepiniqueSft
E 4	763	Repinique1
F 4	764	Repinique2
G 4	765	Repique Open
A 4	766	Repique Rim
B 4	767	Repique Roll

768 Clv&CucaMenu

Key	Wave#	WaveName
C 4	769	Clave!
D 4	770	Claves Lo 2
E 4	774	Cuica Lo 1
F 4	775	Cuica Lo 2
G 4	776	Cuica Hi 1
A 4	777	Cuica Hi 2

778 MrcsShkrMenu

Key	Wave#	WaveName	
C 4	779	Maracas 2	
D 4	780	MaracasUpDwn	
E 4	786	Shaker Long	
F 4	787	Shaker Short	
G 4		Shaker Lite	*

Menu Waveform (3)

782 Shaker MENU

Key	Wave#	WaveName	
C 4	783	Shaker Ptn	
D 4	784	Shaker 1	
E 4	785	Shaker 2	

792 Guiro Menu

Key	Wave#	WaveName	
C 4	793	Quide Long	
D 4	794	Quide Short	
E 4	795	Guiro Long2	
F 4	796	Guiro Short2	
G 4	797	RecoRecoLng	
A 4	798	RecoRecoSht	
B 4	799	MtlGuiroLng	
C 5	800	MtlGuiroSht	
D 5		MtlGuiroAtc	*
E 5		MtlGuiroMut	*

801 CbsCxGnzMenu

Key	Wave#	WaveName
C 4	802	Real Cabasa1
D 4	803	Real Cabasa2
E 4	804	Cabasa Roll
F 4	807	Caxixi
G 4	808	Ganza Soft
A 4	809	Ganza Hard

812 PandeiroMENU

Key	Wave#	WaveName
C 4	813	PandeiroL Lo
D 4	814	PandeiroL Hi
E 4	815	PandeiroL Sp
F 4	816	PandeiroL Rm
G 4	817	PandeiroS Op
A 4	818	PandeiroS Sp
B 4	819	PandeiroS Rm

820 PandTambMenu

Key	Wave#	WaveName
C 4	821	PandeiroOpen
D 4	822	PandeiroMute
E 4	823	PandeiroHit
F 4	824	PandeiroRim
G 4	825	PandeiroCrsh
A 4	826	PandeiroRoll
B 4	831	TamborimOpen
C 5	832	TamborimRim
D 5	833	TamborimMute
E 5	834	TamborimRoll
F 5	835	Tambrin Hit
G 5	836	TambrinShake

827 TamborimMENU

Key	Wave#	WaveName
C 4	828	Tamborim Opn
D 4	829	Tamborim Mut
E 4	830	Tamborim Slp

838 Others Menu

Key	Wave#	WaveName
C 4	839	ApitoHiShort
D 4	840	ApitoLoShort
E 4	842	Quijada
F 4	843	Chekere 3

844 CajonClpMenu

Key	Wave#	WaveName
C 4	845	Cajon Lo
D 4	846	Cajon Hi
E 4	847	Cajon Rol Hi
F 4	848	Cajon Rol Lo
G 4	852	Hand Clap 2

855 BomboBbnMenu

Key	Wave#	WaveName	
C 4		Bombo Open	*
D 4		Bombo Mute	*
E 4		Bombo Rol	*
F 4		Bubans 1	*
G 4		Bubans Rol	*

856 SoftSet Menu

Key	Wave#	WaveName
C 2	745	Surdo Open1
D 2	757	Caixa Mute2
E 2	822	PandeiroMute
F 2	762	RepiniqueSft
C 4	706	Bongo LoOpmf
D 4	714	CongaLoOp mf
E 4	730	Timbles HiMt
F 4	550	BongoBell Op
G 4	802	Real Cabasa1
A 4	786	Shaker Long
B 4	808	Ganza Soft
C 5	775	Cuica Lo 2
D 5	795	Guiro Long2

857 HardSet Menu

Key	Wave#	WaveName
C 2	746	Surdo Open2
D 2	756	Caixa Open3
E 2	821	PandeiroOpen
F 2	761	RepiniqueHrd
C 4	704	Bongo Lo Hrd
D 4	713	CongaLoOp f
E 4	729	Timbles HiOp
F 4	552	MamboBell Op
G 4	803	Real Cabasa2
A 4	787	Shaker Short
B 4	809	Ganza Hard
C 5	774	Cuica Lo 1
D 5	793	Quide Long

* *Used only in the menu waveforms.*

* このウェーブフォームはメニュー・ウェーブフォームのみで使用しています。

About the New Format

Expansion boards SRX-01-04 could only hold a maximum of 128 Patches. In order to make it possible to provide an even greater variety of sounds, a new format (implemented originally on the SRX-05) is now being employed. This new format is capable of handling more than 128 Patches.

If you are using one of the five models listed below, and are still using an older version of the system, you may need to upgrade its system to enable it to support the new SRX format. Check the system program version of your instrument; if your current version is the same as, or older than the corresponding one listed below, use the system update program on the included CD-ROM to upgrade to the latest version before using the SRX-09.

- Fantom (FA-76): Update required for versions up to Ver. 1.12
- XV-5080: Update required for versions up to Ver. 1.24
- XV-3080: Update required for versions up to Ver. 1.08
- XV-88: Update required for versions up to Ver. 1.07
- RD-700: Update required for versions up to Ver. 1.04

For instructions on checking the system program version for each instrument, and upgrading the software, refer to the html files for the relevant instrument included on the CD-ROM.

About the Included CD-ROM

The included CD-ROM features:

- System update programs compatible with new-format SRX expansion boards (for Fantom (FA-76), XV-5080, XV-3080, XV-88, and RD-700)
- Data Reproducing the SR-JV's Original Patches and Rhythm Sets (Compatible models: Fantom (FA-76), XV-5080, XV-5050, XV-3080, XV-88, XV-2020)
- SRX-01–09 demo songs
- BPM Conversion Table

For more detailed information on each file, refer to index_e.html on the CD-ROM.

* *Take proper care of the included CD-ROM; it will not be reissued.*

* *The system programs on the included CD-ROM are the latest versions, as of September, 2002. For information regarding newer versions than those on this disk, you should contact the nearest Roland Service Center.*

新フォーマットに関して

エクスパンション・ボード SRX-01 ～ 04 は、最大 128 パッチを収録していました。SRX-05 以降は、より多彩な音色をお客様に供給する為に、128 以上のパッチを扱えるよう、新フォーマットを採用しています。

これにより、以下の 5 機種において、現在お使いのバージョンによっては、新フォーマットに対応するためにバージョン・アップしていただく必要があります。システム・プログラム・バージョンをご確認の上、下記のバージョン、もしくはそれより古いバージョンの場合は、付属 CD-ROM に収録のシステム・アップデート・プログラムを使用して、製品をバージョン・アップしてから SRX-09 をお使いください。

- Fantom（FA-76）：Ver1.12 まではアップデートが必要
- XV-5080：Ver1.24 まではアップデートが必要
- XV-3080：Ver1.08 まではアップデートが必要
- XV-88：Ver1.07 まではアップデートが必要
- RD-700：Ver1.04 まではアップデートが必要

各機種のシステム・プログラム・バージョンの確認方法、およびバージョン・アップ方法は、付属 CD-ROM に収録の、各機種別ファイルを参照してください。

付属 CD-ROM について

付属 CD-ROM には

- SRX エクスパンション・ボード新フォーマット対応用システム・アップデート・プログラム（Fantom（FA-76）、XV-5080、XV-3080、XV-88、RD-700）
- SR-JV オリジナル Patch / Rhythm Set 再現データ（対応機種：Fantom（FA-76）、XV-5080、XV-5050、XV-3080、XV-88、XV-2020）
- SRX-01 ～ 09 デモ・ソング
- BPM 変換テーブル

が収録されています。各ファイルの詳しい内容は、CD-ROM 内の index_j.html 参照してください。

※ 付属 CD-ROM は再発行しませんので、大切にお使いください。

※ 付属 CD-ROM に収録の各システム・プログラムは、2002 年 9 月時点での最新のものです。収録バージョンより新しいプログラムに関しては、もよりのローランド・サービスにお問い合わせください。

Copyright © 2002 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

© 2002 ローランド株式会社 本書の一部、もしくは全部を無断で複写・転載することを禁じます。

This product must be disposed of separately
at your local waste recycling centre.
Do not dispose of in household waste bin.

03122789 07-04-7N